

ALBUM № A-1  
АНК-5В autopilot  
operating instruction.  
/2-nd edition/

1

secret

Copy No. \_\_\_\_\_

AIM-5B

AUTOPILOT OPERATING INSTRUCTIONS

(2-53 edition)



1

secret  
Copy No. \_\_\_\_\_

AUG-5B      AUTOPILOT OPERATING INSTRUCTIONS

(2nd edition)

9. Calibrating the ANK-5B	
autopilot output signals.....	53
SECTION III. ANK-5B AUTOPILOT STORAGE	58
10. Requirements to the ANK-5B	
autopilot storage.....	58
11. Periodic checks of the ANK-5B	
autopilot in storage.....	61
12. Checking the ANK-5B autopilot	
operation in storage without	
removing it from the K-1M missile	64
13. Checking the ANK-5B autopilot	
operation in storage with some	
units removed from the missile..	71
14. Checking the ANK-5B autopilot	
when storing it packed in turn..	74
15. Procedure of replacing the	
ANK-5B autopilot individual	
units and components.....	72
SECTION IV. ANK-5B AUTOPILOT PRE-FLIGHT TEST..	81
16. Separate checkout of the ANK-5B	
autopilot .....	81
17. Combined checkout of the ANK-5B	
autopilot and K-1M station.....	86
SECTION V. ANK-5B AUTOPILOT TAKE BEFORE A	
TAKE-OFF .....	89
18. Testing the ANK-5B autopilot by	
using the carrier-aircraft	
equipment .....	89

	Page
9. Calibrating the ALA-5B autopilot output signals.....	53
SECTION III. ALA-5B AUTOPILOT STORAGE	58
10. Requirements to the ALA-5B autopilot storage.....	58
11. Periodic checks of the ALA-5B autopilot in storage.....	61
12. Checking the ALA-5B autopilot operation in storage without removing it from the missile	64
13. Checking the ALA-5B autopilot operation in storage with some units removed from the missile..	71
14. Checking the ALA-5B autopilot when storing it packed in tank..	74
15. Procedure of replacing the ALA-5B autopilot individual units and components.....	78
SECTION IV. ALA-5B AUTOPILOT PRACTICE TEST..	81
16. Separate checkout of the ALA-5B autopilot .....	81
17. Combined checkout of the ALA-5B autopilot and E-4H station.....	86
SECTION V. ALA-5B AUTOPILOT SHOT BEFORE A PRACTICE OFF .....	89
18. Testing the ALA-5B autopilot by using the carrier-aircraft equipment .....	89

9. Calibrating the AIM-5B	
autopilot output signals.....	50
SECTION III. AIM-5B AUTOPILOT STORAGE	58
10. Requirements to the AIM-5B	
autopilot storage.....	58
11. Periodic checks of the AIM-5B	
autopilot in storage.....	61
12. Checking the AIM-5B autopilot	
operation in storage without	
removing it from the "K" missile	64
13. Checking the AIM-5B autopilot	
operation in storage with some	
units removed from the missile..	71
14. Checking the AIM-5B autopilot	
when storing it packed in barrel.	74
15. Procedure of replacing the	
AIM-5B autopilot individual	
units and components.....	75
SECTION IV. AIM-5B AUTOPILOT PRE-FLIGHT TEST..	81
16. Separate checkout of the AIM-5B	
autopilot .....	84
17. Combined checkout of the AIM-5B	
autopilot and F-4H station.....	86
SECTION V. AIM-5B AUTOPILOT TEST BEFORE A	
TAKE-OFF .....	89
18. Testing the AIM-5B autopilot by	
using the carrier-aircraft	
equipment .....	89

	4
	Page
SECTION VI. A11-53 ADAPTIVE PERIODIC MAINTENANCE	
START LINE .....	92
19. A11-53 autopilot periodic main- tenance operations procedures.....	93
20. Periodic maintenance operations record .....	94
SECTION VII. A11-53 AUTOPILOT TEST EQUIPMENT.....	102
21. A11-53 autopilot set test equip- ment.....	102
22. A11-53 autopilot units test equipment .....	112
APPENDIX .....	115

## P R E F A C E

The "AHK-5B Autopilot Operating Instructions" are intended for the plants, manufacturing "KC" winged missiles, and mechanical personnel of the using organizations.

The "AHK-5B Autopilot Operating Instructions" are the manual for storage, shipment, installation, checks and maintenance of the AHK-5B autopilot within the guaranteed service life.

The main form of storing the AHK-5B autopilot is keeping it in the "KC" winged missile being preserved in accordance with the present instructions KC-05-WM, edition III for preservation and extended storage of the "KC" missile in the depots for one year since the date of arrival to the point of destination.

The complete autopilot equipment may be installed in the "KC" missile or the H-2 gyro unit may be removed from it; in this case this unit is stored in a special metal tare.

The AHK-5B autopilot is permitted to be stored in the "KC" missile in a hangar for 3 months within the entire guaranteed service life.

The AHK-5B autopilot and its individual units which are not installed in the "KC" missile can be stored in the depots packed in special metal tare for one year since the date of arrival to the point of destination.

The AHK-5B autopilot and its individual units can be transported in tare or installed in the "KC" missile.



The requirements for the AUK-5B autopilot shipment are outlined in these instructions. The autopilot installed in the "KC" missile is shipped in accordance with the "KC" Winged Missile Maintenance and Operating Instructions", Book I.

The autopilot must be installed in and removed from the "KC" missile according to the "KC" Winged Missile Maintenance and Operating Instructions" Book I.

The amount and methods of the AUK-5B autopilot checkouts at the "KC" missile manufacturing plant, during an extended storage and also during the pre-flight test and test before a take-off are given in these instructions.

## SECTION I


## PACKING AND SHIPMENT OF THE ANK-5B AUTOPILOT

I. INSTRUCTIONS FOR PACKING THE ANK-5B AUTOPILOT UNITS IN  
CASE

1. The tare for the ANK-5B autopilot consists of 2 welded metals cases. Packed in one of the cases are II-1 and II-2 units and in the other - II-4 and II-18MO units and HAP-10A inverters. The cases are made according to drawings No.399.00.00.000 (for II-1 and II-2 units) and No.400.00.00.000 (for II-4, II-18MO units and HAP-10A inverters).

The external view of one of the cases is given in Fig.1. Furnished with the metal case made according to dwg.No.399.00.00.000 is the box (dwg.399.01.00.000) with the plug connectors.

2. The rooms in which the ANK-5B autopilots are packed should meet the requirements indicated in para.10.





3. Pack the II-1 control panel and II-2 gyro unit in boxes as follows:

Install the II-1 control panel on the shock mounts (2) of the mounting (1, Fig. 2) and secure it by 4 screws with nuts. Pack the cables plug connectors with two sheets of oil paper (FOOT 1760-51) and herringbone tape and bind the tape with linen threads.

Insert the plug connectors in the holders (3). Secure the cables by the tape with the button (4). Fasten the control panel filter in the clamp (6).

Install the II-2 gyro unit on the shock mounts (2) of the mounting (1, Fig. 3) and secure by 3 bolts. Attach the II-2 gyro unit plug connectors No. 31, 39, 42 (manufactured specially for the II-2 gyro units) 43, 45 and 47 to the flanges (3) using their coupling nuts. Fasten plug connector No. 35 to the flange (4) by a coupling nut.

Cover the bent portions of cables No. 39, 42 and 43 with a split chlorvinyl tubes (7, dia. 34) and secure them by the tape with the button (2) to the mounting.

Secure cables No. 31, 35 and 44 by the tape with the button (9), cover them with the split chlorvinyl tube (10) and fasten them to plug connector No. 35 by the tape with the button (11). Cover cables No. 45 and 47 with the split chlorvinyl tube (12) and fasten them to plug connector No. 45 by the tape with the button (12, Fig. 3).

Secure the II-2 gyro unit filter to the mounting with the II-1 control panel by means of a clamp and plug connector No. 44 by means of its coupling nut - to the flange located on the same mounting.

Move the mountings with the H-I and U-2 units installed along the guide rails into the case placed on the floor; see that the mountings are in the vertical position. The mountings must move along the rails without shaking and sticking. If necessary, bend the guide rails.

Secure cables No.45 and 47 to cable No.44 by the tape with the button (1) and place them in the box (2, Fig.4) manufactured according to dwg. No.399.01.00.000, with the plug connector mating parts furnished with the autopilot set.

NOTE: The chlorvinyl tubes may be substituted by chlorvinyl tape.




Fig.2. H-I Control Panel-to-Mounting  
Attachment




Fig. 3. H-2 Cyro Unit-to-Mounting Attachment




Fig. 4. H-1 and H-2 Units in Tare



Prior to installation, place in each mounting bag (5, Fig.2 and 3) with "FOCI" silica gel dehydrator, 100 gr. (FOCI 3956-47) and in the E-2 case with mounting bag (6, Fig.3) with blue silica gel indicator, 100 gr.

Place the silica gel bags so that they cannot shift during shipment. It is permitted to tie the bags to the cables or mounting with the E-2 case cable harness threads or fasten them by tapes with buttons.

- NOTES:
1. When placing the bags in the autoclave silica gel dehydrator humidity must not exceed 2%.
  2. The silica gel dehydrator type 100 gr. can be substituted by silica gel type "FOCI" (FOCI 3956-47).
  3. If a cartridge with silica gel - indicator is placed in the case, the bag (5) with silica gel indicator should not be put in the case.
  4. When packing the E-2 case (manufactured with plug No.42) which is incorporated in the autopilot set installed in the E-2 missile, place in the case the bag for the above mentioned plug attached the plug with the clamp (6, Fig.2).

On accomplishing the packing, furnish the case with a packing list of a given standard, close the case with the cover, fasten the latter with 16 bolts, secure the case with two seals 1052A55 at the corners located obliquely and mark with an indelible black paint the number of the autopilot set on the right upper corner of the cover and top wall of the case.




Fig. 6 Testing the Packing Cases for Flight.

Install the  $\Pi-4$  servo units (1) on the mounting (1, Fig. 6) and secure each unit by 4 bolts with nuts.

Coat the  $\Pi-4$  servo units of the shafts with IN (100)  $\mu$  lubricant.

Install the  $\Pi-1000$  timer on the mounting (2) and secure it by 4 screws with nuts.

Wrap each plug connector of the  $\Pi-1$  servo units of  $\Pi-1000$  timer cables with two sheets of mill paper or herringbone tape and tie the tape with linen threads.

Insert the plug connectors in the holders (3). Fasten the  $\Pi-4$  servo units to the clamps (4). Secure the cables by the tape with the button (7).

Tighten the HAF-10A inverters (2 ea) to the mounting (1, Fig.7) by the screws with nuts, wrap the end caps and plug connectors of the inverters with two sheets of oil paper (Fig.7) and tie the oil paper with linen threads.

Move the mountings with the H-4 servo units and H-18MO timer and mounting with the HAF-10A inverters into the case using the guide rails (Fig.8).

The mounting should move along the guide rails without shaking and sticking.

If necessary, bend the rails. The mountings must be moved into the case placed on the floor in the vertical position.




Fig. 8. H-4 Servo Units and H-18MO Timer to Mounting Attachment



Fig.7. HAP-IGA Inverter-to-Mounting Attachment




Fig.8. R-1 Servo Units, H-18MO Timer and HAP-IGA Inverters Installed in Rack.

Before installing the mountings, place on the mounting with H-4 servo units and H-10MO timer two bags (5) with "KCM" silica gel dehydrator, 200 grm. each and the bag (6) with a blue silica gel - indicator, 15-20 grm. The bags must be placed so that they are not moved during transportation. It is permitted to tie the bags to the cables with linen threads or secure them by tapes with buttons (Fig.6).

- NOTES:
1. When placing the silica gel dehydrator bags in the case, silica gel humidity must not exceed 2%.
  2. The silica gel type "KCM" may be substituted by silica gel type "MCM", "HCT" and "LCT".
  3. If a special cartridge with silica gel-indicator is installed in the case, the bag (6) with silica gel-indicator must not be placed in the case.

On accomplishing the packing, furnish the case with the packing list of a given standard, close the case with the cover, attach the case cover with 14 bolts, secure the case with two seals 1053A55 at two corners located obliquely (Fig.1) and mark with an indelible black paint the number of the autopilot set in the right upper corner of the cover and upper wall of the case.

Test the case welded seams tightness and tight fitness of the cover in the same way as for the case with H-1 and H-2 units (see step 3).

NOTE: When packing the autopilot in the using organization it is permitted, as an exception, not to put the silica gel bags in the case and to test the case for airtightness.



## 2. INSTRUCTIONS FOR PACKING THE AIM-53 AUTOPILOT UNITS IN SHIPPING BOXES

1. To transport the AIM-53 autopilot set or its individual units, the metal cases are additionally placed in the wooden shipping boxes manufactured according to dwg. No.464.00.00.000.

2. When packing the autopilot set in the shipping boxes, proceed as follows:

Open the upper cover of the shipping box. Carefully, without jerks and shocks, place the metal <sup>case</sup> in the shipping box so that the case position would correspond to the inscriptions made on the case.

Placed between the walls of the shipping box and metal case are plywood and felt spacers to prevent the metal case from shifting inside the wooden box (Fig.9).

Close the upper cover, secure the box with four iron strips and two seals 1053A55.

On accomplishing the packing, mark with an indelible black paint the number of the autopilot set in the right upper corner of the cover.

NOTE: When packing the H-2 gyro unit incorporated in the autopilot set installed in the "KC" missile, additionally mark on the case cover the number of the "KC" missile in which the H-2 gyro unit is to be installed.




Fig.9. Packing Case in a Shipping Box

### 3. AH-1B AUTOPILOT UNPACKING INSTRUCTIONS

1. When unpacking the shipping boxes, proceed as follows:

Check for presence of seals on the box. Remove the iron strips and upper cover of the shipping box.

Take out the plywood and felt spacers placed between the wooden box and metal case. Carefully remove the metal case from the wooden box so that the metal case position would correspond to the inscriptions made on the case.

2. Unpack the packing cases with the H-1 and I-2 units as follows:

Check the case for freedom from damages and for presence of seals.

Break the seals and unscrew 14 bolts attaching the <sup>wall</sup>~~side~~. Make sure that the packing list is furnished. Check for presence of units and their numbers according to the packing and completing lists.

Inspect the silica gel-indicator. If the silica gel-indicator has become pink, replace the silica gel-indicator and silica gel dehydrator before a repeated packing.

NOTE: The autopilot units stored in the cases with pink silica gel-indicator should not be subjected to special checks; the units serviceability is determined during the next periodic check.

Remove the tape with the button securing cables No. 45 and 47 to cable No. 44.

Simultaneously take the mountings with the H-1 and H-2 units out of the case so that the units would be in the horizontal position.

Disconnect the H-2 gyro unit plug connector No. 44 from the flange located on the mounting with the H-1 unit and release the H-2 gyro unit filter from the clamp located on the same mounting.

Remove the tapes with the buttons, securing the cables and unscrew the remaining plug connectors of the H-2 gyro unit from the mounting flanges.

Remove the silica gel bags.

Unscrew 3 bolts and remove the H-1 gyro unit from the shock-mounts of the mounting. Move the mounting in the case along the guide rails. Unscrew the screw of the clamp, release the H-1 control panel filter and take out the H-1

control panel plug connectors from the holders. Remove the tapes with buttons securing the cables.

Remove the herringbone tape and oil paper from the plug connectors.

Unscrew four screws and remove the H-1 control panel from the mounting shock-mounts. Move the mounting in the case along the guide rails.

Attach the side wall by 2 bolts and place the remaining 12 bolts inside the case.

3. Unpack the cases with the H-1 servo units, H-18MO timer and HAP-12A inverters as follows:

Check the case for freedom from damages and for presence of seals.

Break the seals and unscrew 14 bolts attaching the side wall. Make sure, that the packing list is furnished. Check the units and their numbers according to the packing and completing lists. Inspect the silica gel indicator. If the silica gel has become pink, replace the silica gel-indicator and silica gel-dehydrator before a repeated packing.

NOTE: The autopilot units, stored in the cases with a pink silica gel, should not be subjected to special checks; the units serviceability is determined during the next periodic check.

Remove the mounting with the H-1 servo unit and H-18MO timer so that the units would be in the horizontal position. Remove the silica gel bags.

Unscrew the screws of the clamps, release the H-1 servo unit filters and take out the H-1 servo unit plug connectors from the holders.

Remove the tapes with buttons which secure the cables. Cut the threads, remove the herringbone tape and oil paper from the plug connectors.

Unscrew four screws and remove the H-18M0 timer from the shock-mounts. Unscrew 4 bolts and remove the H-4 servo units from the mounting. Move the mounting into the case along the guide rails.

Take the mounting with the HAP-10A inverters out of the case. Cut the threads and remove oil paper from the end caps and plug connectors of the inverters. Unscrew 4 screws and remove the inverters from the mounting. Move the mounting into the case along the rails.

Attach the side wall by 2 bolts and place the remaining 12 bolts inside the case.

#### 4. ANK-5B AUTOPILOT SHIPMENT

1. The ANK-5B autopilot and its individual units which are not installed in the "KC" winged missile must be shipped in a box according to the requirements indicated in par. 1 and 2, these Instructions.

2. When carrying, loading and shipping the boxes see that the position of the boxes corresponds to the inscriptions made on them. The boxes must be carefully carried and loaded without jerks and shocks.

When shipping, install and attach the boxes so as to protect them from falls, displacement and impacts against each other. Do not transport the autopilot and its individual units

7. The attachment parts must ensure secure attachment of the autopilot units in the missile through out the entire service life. The autopilot units attachment parts and plug connections must be securely locked.

8. Install and remove the autopilot units only with the electrical system de-energized.

9. The requirements for the autopilot unit installation and removal from the missile are given in the "Air Targeted Missile Maintenance and Operating Instructions" (page 1).

6. CHECKING THE AIR-10 AUTOPILOT UNIT BEFORE USE

1. Inspect the autopilot unit before use. Check for signs of damage or wear. Check the unit for compliance with the instructions given in par. 3. Visually inspect all the units. Check the external surfaces of the units and cables for freedom from damage and traces of corrosion.

When checking the AIR-10 autopilot unit, proceed as follows:

2. Remove the AIR-10 autopilot unit from the simulator base and place it in the AIR-10 simulator base and secure it.

3. Set the "POWER" switch to the "ON" position in the "POWER" position.

4. Connect a supply of 115V AC to the control unit.

5. Check the plug connections of the AIR-10 autopilot unit to the control unit.



Set the "PANEL" selector switch in the "I-4" position, "WINDINGS SELECTOR SWITCH" - in the "0" position and "SIGNAL" selector switch in the "60mA" position. Put the "SIGNAL" knob in the "0" position.

4. Switch on the "FEEDBACK" and "POWER" switches. The II-4 servo unit outlet shaft should move to the zero position. Attach the KHA-3 simulator pointer to the outlet shaft, aligning the pointer with the scale zero division. Set the "POWER" switch in the "OFF" position.

Manually turn the servo unit outlet shaft in any direction to the stop. Switch on the "POWER" switch; in this case the II-4 servo unit outlet shaft must move to the zero position to within  $\pm 0.25^\circ$ ; self-oscillations should not appear. Repeat the check with the servo unit outlet shaft turned in the opposite direction.

5. Set the "FEEDBACK" switch in the "OFF" position, the "WINDING SELECTOR SWITCH" - in the "I" position and the "SIGNAL" selector switch in the "3mA" position (for the KI-I control panels, whose "SIGNAL" milliammeter has the scales of "3-0-3mA", "60-0-70mA"). Smoothly turn the "SIGNAL" knob to the right, increase the control signal till the servo unit outlet shaft starts steadily rotating and moves to the limit switch (turning through an angle of  $10-11^\circ$  from the zero position).

The control signal value (in mA) is the unit sensitivity.

When using the KI-I control panel whose "SIGNAL" milliammeter has the scales of "1-0-1mA", "1.5-0-1.5 mA", "2.5-0-2.5mA" and "60-0-60mA", check as described above except for the position of the "SIGNAL" selector switch which must be set before the check in the "1mA" position. If, when turning the "SIGNAL" knob, the

4. Switch on the ~~main~~ ~~power~~ ~~switch~~ ~~and~~ ~~wait~~ ~~for~~ ~~the~~ ~~light~~ ~~to~~ ~~come~~ ~~on~~.

Manually turn the actuator clockwise to the stop. When on the stop, the actuator will be in the "off" position.

3. Unit 10: The World of the Future

The control signal value  $u_{\text{control}}$  is calculated as follows:

Approved For Release 2011/02/07 : CIA-RDP82-00038B001400030001-4



Set the "PANEL" selector switch in the "0" position.  
"WINDING SELECTOR SWITCH" - in the "0" position and "SIGNAL"  
 selector switch in the "0000" position. Set the "TUNE" knob  
 in the "0" position.

4. Switch on the "POWER" switch in the "0" position.  
 The H-4 servo unit will start moving the pointer to the zero position.  
 Attach the H-4 winding selector switch to the "0" position, aligning the pointer with the scale zero mark. Set the  
"POWER" switch in the "0" position.

Manually turn the servo unit until the pointer is at the zero position  
 to the stop. Switch on the "POWER" switch in the "0" position.  
 H-4 servo unit will start moving the pointer to the zero position  
 to within  $\pm 1.5^\circ$ ; self-aligning the pointer to the zero position.  
 the check with the servo unit moving the pointer in the  
 opposite direction.

5. Set the "PANEL" selector switch in the "0" position.  
"WINDING SELECTOR SWITCH" - in the "0" position and "SIGNAL"  
"SIGNAL" selector switch in the "0000" position. Set the  
 control panels, where "TUNE" knob is set to the "0" position.  
"3-0.3mA", "60-70mA", "TUNE" knob is set to the "0" position.  
 the right, increase the "TUNE" knob until the pointer is at the zero  
 let shaft start, it will start moving the pointer to the zero position  
 (turning through the "0" position).

The control panels, where "TUNE" knob is set to the "0" position.  
"TUNE" knob is set to the "0" position.  
 and the "TUNE" knob is set to the "0" position.  
 and "TUNE" knob is set to the "0" position.  
 in the "0" position.

Approved For Release 2011/02/07 : CIA-RDP82-00038R001400030001-4

control signal value, at which the shaft starts releasing, exceeds 1mA, it is necessary to set the "SIGNAL" selector switch in the "1.5mA" position and if these values are exceeded, set the selector switch in the "2.5mA" position.

Repeat checking with the "SIGNAL" knob turned to the left.

The servo unit outlet shaft should move to the opposite limit switch.

When setting in turn, the "SIGNAL" selector switch in the position "1.5mA", check the sensitivity of the servo unit with the "SIGNAL" knob turned to the left. The "SIGNAL" selector switch in the "1.5mA" position the servo unit sensitivity must be within the range of 0.92-1.03 mA.

6. Set the "SIGNAL" selector switch in the "1.5mA" position. Gradually increase the control signal value until the "SIGNAL" knob is at the limit of the range smoothly without jerks.

Gradually increase the control signal value until the "SIGNAL" knob is at the limit of the range smoothly without jerks.

Repeat the check when the "SIGNAL" knob is at the limit of the range. Set the "SIGNAL" selector switch in the "1.5mA" position. Gradually increase the control signal value until the "SIGNAL" knob is at the limit of the range smoothly without jerks.

7. Check the operation of the servo unit when the "SIGNAL" knob is at the limit of the range.

Check the operation of the servo unit when the "SIGNAL" knob is at the limit of the range.

8. Set the "SIGNAL" selector switch in the "1.5mA" position. Gradually increase the control signal value until the "SIGNAL" knob is at the limit of the range smoothly without jerks.

Connect supply of 26 V A.C. to the control panel.

Connect the control panel cable to the plug connector of one of the HAI-10A inverters.

9. Switch on the "POWER" and "IDAP" switches.

The gyro motors installed in the control panel must start rotating. After 2 min. check by the control panel A.C. ammeter the current drawn by the inverter which under normal conditions must not exceed 2.5 A.

When checking the autopilot at a temperature different from the normal temperature within a range of  $-35^{\circ}\text{C}$  to  $+50^{\circ}\text{C}$ , increase the above mentioned tolerance by 0.06A for each  $10^{\circ}\text{C}$  of the temperature change either side from normal.

10. Set the "PHASE SELECTOR SWITCH" in the "1" position. Check A.C. voltage generated by the inverter using the control panel A.C. voltmeter and the alternating current generated by the inverter using the control panel A.C. ammeter. Under normal conditions voltage should be equal to  $36 \pm 4$  V and current should not exceed 2.5 A.

When checking at a temperature different from the normal temperature within a range of  $-35^{\circ}$  to  $+50^{\circ}\text{C}$ , increase the 4 V tolerance of the voltmeter readings by 0.2 V for every  $10^{\circ}\text{C}$  of the temperature change either side from normal.

In the temperature range indicated below and other similar conditions the tolerance for the ammeter, must be increased:


at  $T = +20$  to  $-35^{\circ}\text{C}$  by 0.051 A

at  $T = +20$  to  $+50^{\circ}\text{C}$  by 0.012 A.

Set the "PHASE SELECTOR SWITCH" in the "2" and "3" positions and check voltage and current in two other phases of the inverter.



Unit No 12 to ANA-5B output at specifications




Plug connectors are arbitrarily designated.

(example)

- plug connector No. 35.

secret

# ent No. 12 to ANK-5B outpilot specifications



NOTE: Plug connectors are arbitrarily designated.  
 Symbol (example)  
 — 35 — - plug connector No. 35.

29

FIG. 10. Block Diagram of AHC-52 autopilot Unit's Connection with Test  
Set.

Attach the KMA-3 simulator pointers to the H-4 servo unit outlet shafts and set the pointers at zero points on the simulator scales.

NOTES: a) Before energizing the autopilot, check the "CENTERING" potentiometer wipers position on the H-1 control panel; in this case the slot on the potentiometer shaft must be against the index on the panel cover.

b) After illumination of the "CHECKS OK" warning lights but not earlier than 3 min. after power is applied, set the selector switch on the H-1 panel in the "RIGHT" position. Set the "PRESS-TO-TEST" knob of the H-1 panel in the "UP" position, the milliammeter pointer on the H-1 panel must deflect "UP", approx. one division. Press the "ALIGNING" button on the H-1 control panel, the "CHECKS OK" warning light must go out and the "CHECKS OK" warning light must come on, the elevator simulator pointer must deflect  $1^{\circ}42'$  to the left. Turn the "PRESS-TO-TEST" knob of the H-1 panel in turn to the left and to the right. The pointers of the elevator simulator and milliammeter on the H-1 panel must be motionless. Set the "PRESS-TO-TEST" knob on the H-1 panel in the zero position and change the selector switch from the "RIGHT" position to the middle position.



31

the off power supply on the 10-1  
control panel and after 5-10 sec.  
energize the autopilot again. Last,  
with the WARNING light  
comes on.

- e) After the WARNING warning light  
illumination, repeat the check  
described in 1. with the pre-  
set only knob on the 10-1 panel  
set in 10, 11, 12 and 13 position.  
In this case the vertical surface  
of the indicator will be in a position 100%  
of the value 1. Indicated by the pre-set  
knob of the 10-1 panel.
- Repeat the check for the 10-1 panel  
control unit. Set it down in the 10,  
11, 12, 13, 14 and 15 position. In  
all cases the pre-set knob of the  
10-1 panel must be set in the  
10 position. The surface indicator must set.  
The 10-1 panel (as shown from the  
surface) must be set.

1. Turn the 10-1 panel pre-set  
knob to the left or to the right  
in the range of 10 to 15, then WARNING  
warning light may remain illu-  
minated.
2. Turn the 10-1 panel pre-set  
knob to the 10-15 position.

the air power supply on the (M-1) control panel and after 5-10 sec. energize the autopilot again. Wait, until the BASES warning light comes on.

- c) After the BASES warning light is like initial, repeat the check according to step 1) with the pre-set unit knob on the (M-1) panel set in one of 1°, 4°, 7° and 9° position. In this case the control surface deflection must occur as within  $\pm 3\%$  of the value indicated by the pre-set knob on the (M-1) panel.

When the check of the (M-1) panel pre-set unit knob set down in the 1°, 4°, 7°, 9° and 9° positions, in a 10 sec. and 10 sec. interval of the check the unit must be set down and the control surface simulator must def. to the zero light (as viewed from the nose or tail).

1. When switching the (M-1) panel pre-set unit knob to the left or to the right in the range of 0° to 2°, the BASES warning light may remain illuminated.

2. When switching over to the (M-17K

Simulator, the direction indicator on the U-2 model is inoperative.

10. After the "Warning" warning lights come on (but not earlier than 5 min. after power is supplied) set the "BOARD" indicator light on the control panel in the "BOARD" position and check on the "U-2" switch.

The "BOARD" and "U-2" warning lights must come on. Sharply left or right U-2 gyro unit in direction; at the instant of turning the U-2 gyro unit, the U-2 rudder servo unit outlet shaft must turn. Repeat the check when turning the U-2 unit in the opposite direction.

Perform similar checks when turning the U-2 gyro unit in the opposite direction.

11. Rotation of the U-2 servo unit starts rotation of the U-2 model. The positions of the control panel and position indicators, when the U-2 gyro unit is turned in the directions indicated in Table No. 1, must move to the left.

Table No. 1.

Channel	Direction of U-2 gyro unit turn	Direction of outlet servo rotation		
		U-2 rudder servo unit	U-2 elevator servo unit	U-2 aileron servo unit
Direction	to the right	counter-clockwise	-	-
Pitch	up	-	clockwise	-
Roll	to the right	-	-	clockwise

NOTE: After the U-2 gyro unit is stopped, the U-2 servo unit outlet shafts must return to the zero position to within  $\pm 0.25^\circ$ .

15. Fully turn the "AUXILIARY" knob on the control panel to the "RIGHT". The B-4 rudder servo unit outlet shaft must smoothly, without jerks, turn clockwise and the B-3 aileron servo unit outlet shaft - counterclockwise. Fully turn the "RUDDER" knob to the "LEFT". The B-4 rudder servo unit outlet shaft must smoothly, without jerks, turn counterclockwise and the B-3 aileron servo unit outlet shaft - clockwise. Set the "RUDDER" knob in the zero position.

Fully turn the "ELEVATOR" knob on the control panel to the "UP" position.

The B-4 elevator servo unit outlet shaft must smoothly, without jerks, turn counterclockwise. Fully turn the "ELEVATOR" knob to the "DOWN" position. The B-4 elevator servo unit shaft must smoothly, without jerks, turn clockwise. Set the "ELEVATOR" knob in the zero position and the "CLIMB" switch in the "UP" position. Wait till the B-4 servo units outlet shafts move to the zero position and "HAZARD LIGHT" warning lights come on.

17. Set the "FLIGHT SIMULATOR SWITCH" in the "FLIGHT SIMULATOR" position. The "FLIGHT SIMULATOR" warning light must become illuminated. Press the "UNCOUPLING" button on the control panel and simultaneously start the stop-watch; in this case the "CAGE" warning light must go out and "UNCOUPLING" warning light must come on. 2-3 sec. after the "UNCOUPLING" button is pressed, the B-4 elevator servo unit outlet shaft must turn counterclockwise through an angle of  $9-9.5^\circ$  and 40-42 sec. after the button is pressed, the outlet shaft must return to the zero position to within  $\pm 0.55^\circ$ . Perform the check twice. When uncoupling for the first time, check the B-4 servo

power of 28.6 V D.C. to the control panel. Set the "PANEL" selector switch in the "I-4" position, the "WINDING SELECTOR SWITCH" - in the "0" position and the "SIGNAL" selector switch - in the "COM" position. Set the "SIGNAL" knob in the "0" position.

3. Switch on the "POWER" and "FEEDBACK" switches, in this case the I-4 aileron servo unit shaft must turn to the zero position.

Check the ailerons position. If the ailerons are deflected from the neutral position (i.e. the ailerons neutral position does not correspond to the zero position of the I-4 servo unit) set the ailerons in the neutral position by changing the rod length using the adjustment elements.

4. Set the "FEEDBACK" switch in the "OFF" position and "WINDING SELECTOR SWITCH" - in the "I" position. Slowly rotating the "SIGNAL" potentiometer knob, first in one and then in the other side of zero position, determine the ailerons maximum angle of deflection (till the I-4 servo unit limit switches are actuated) which must be within  $\pm 9.5$  to  $11.5^\circ$  from the neutral position.

5. Set the "SIGNAL" knob in the "0" position, switch on the "FEEDBACK" switch and check that the ailerons are set in the neutral position again; in this case permissible angle of the ailerons deflection from the neutral position is up to  $0.25^\circ$ .

6. Set the "POWER" switch in the "OFF" position and manually deflect the ailerons in either side to the stop; then switch on the "POWER" switch, in this case the ailerons



must move to the neutral position and self-oscillation must not occur.

Repeat the check with the ailerons deflected to the opposite side. Set the "POWER" switch in the "OFF" position and disconnect the H-4 aileron servo unit plug connector from the control panel.

7. Check the H-4 rudder and elevator servo units for proper installation (steps 2-6).

NOTE: The elevator neutral position is the deflection through  $2.5-3^{\circ}$  up from the geometric neutral position. Further, this position of the elevator is called "ZERO" position.

#### 8. TESTING THE ANK-5B AUTOPILOT AFTER INSTALLATION IN THE "KC" MISSILE

1. To check the ANK-5B autopilot after installing it in the "KC" missile, remove the H-2 gyro unit from the missile irrespective of the preservation to which the given "KC" missile will be subjected after it is accepted by the Customer.

2. Install the H-2 gyro unit on the KIA-5 turn table according to the instructions given in step 12, par. 6.

NOTE: It is permitted to install the H-2 gyro unit on the KIA-5 turn table without removing the gyro unit from the mounting.

3. Place the H-2 gyro unit secured to the turn table at a distance of 1-2.5 m. from the access door in the fuselage bottom section between frames 14 and 18.

NOTE: When installing the turn table see that it does not slide on the base.

4. Connect the II-2 gyro unit plug connectors observing the numbers on the plug connectors and the autopilot wiring diagram (Fig.11), in this case:

a) connect the II-2 gyro unit receptacles No.31, 35, 39, 43 and 47 to the mating plugs of the missile wiring system through the connecting cables;

b) connect the II-2 gyro unit receptacle No.4 to the mating plug of the IIIA-1 control panel through the connecting cable; the IIIA-1 control panel plug connector No.42 through the connecting cable - to the plug connector No.36 used for checking the autopilot installed in the missile and the II-2 gyro unit plug connector No.45 - to the IIIA-1 and III-3 control panels through the connecting cable according to the block diagram given in Fig.10.

NOTES: 1. Do not connect plug connectors when the system is energized.

2. Connect the autopilot to the missile and energize the system to check it only after the missile wiring system is approved by the

Inspection Department and by the Master.

When checking the autopilot operation, proceed as follows:

1. Supply power of 28 ± 0.5 V d.c. to the missile

and system switch on the "POWER" switch on the

panel. In this case the III-1 gyro unit's status

the "AC-200" warning lights are (no later than 10 sec)

"E-200" warning light come on. Do not touch

the "AC-200" warning light



The rudder and ailerons must be set in the neutral positions to within  $\pm 0.5^\circ$  and the elevator must be set  $2.5-3^\circ$  Up from the geometric neutral position (further, this position of the elevator is called a "ZERO" position). The control surfaces position indicators pointers must be in the middle positions.


a) After the "BASES ZERO" warning lights become illuminated, but not earlier than 3 min. after power is supplied, set the "B" selector switch on the III-A control panel in the "TO THE RIGHT" position. Set the pre-set unit knob on the III-A control panel in the position 4 divisions down. The pointer of the millimeter on the III-A panel must deflect down approx. 4 divisions. The "BASES ZERO" warning light on the KHA-1 control panel must go out. Press the "UNCAGING" button; the elevator must move through an angle of  $4^\circ \pm 1^\circ 24'$  down from the initial position.

Turn the pre-set unit knob on the III-A control panel "UP", "DOWN" and then set it in the zero position.

The elevator must be motionless. Set the selector switch on the III-A control panel in the middle position.


De-energize the autopilot. Repeat the check with the pre-set unit knob set in the  $3^\circ$  and  $6^\circ$  positions.

b) Repeat the check as specified in step "a" with the pre-set unit knob set  $4^\circ$  "UP". In this case the elevator must move through an angle of  $4^\circ \pm 1^\circ 24'$  up.



- to TKC System  
see dwg. KC-7406-10
- 2) Test plug connector WIP48NK243W2
  - 3) П-4 servo unit (ailerons)
  - 4) П-4 servo unit (rudder)
  - 5) П-4 servo unit (elevator)
  - 6) Filter
  - 7) П-18M0 timer
  - 8) П-2 gyro unit
  - 9) Cable No. 9
  - 10) Cable No. 1
  - 11) K-1-13M unit
  - 12) Cable No. 3
  - 13) ПАГ-1ΦА inverter
  - 14) Cable No. 2
  - 15) П-1 control panel
  - 16) ПН-2 relay
  - 17) K-20A contactor
  - 18) Junction box (see dwg. 7201-00)

Fig. 14. Autopilot wiring diagram



- 1) Cable N. 11/4  
to TKC System  
see dwg. KC-7406-10
- 2) Test plug connector WIP48AK243W2
- 3) 11-4 servo unit (ailerons)
- 4) 11-4 servo unit (rudder)
- 5) 11-4 servo unit (elevator)
- 6) Filter
- 7) 11-18M0 timer
- 8) 11-2 gyro unit
- 9) Cable No. 9
- 10) Cable No. 1
- 11) K-1-13M unit
- 12) Cable No. 3
- 13) 11A1-10A inverter
- 14) Cable No. 2
- 15) 11-1 control panel
- 16) 211-2 relay
- 17) K-20A contactor
- 18) Junction box (see dwg. 7201-00)

Fig. 11. KC-7406-10 Autopilot wiring diagram



4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MD timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of  $\pm 45^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $10^\circ$  in the direction opposite to that checked. Then, one minute after the auto-pilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within  $\pm 25^\circ$ .

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-3 gyro unit through an angle of  $\pm 45^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-3 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $40^\circ$  in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-3 unit in pitch within  $\pm 25^\circ$ .

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-3 gyro unit through an angle of  $\pm 45^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-3 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $10^\circ$  in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-3 unit in pitch within  $\pm 25^\circ$ .

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of  $\pm 45^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $10^\circ$  in the direction opposite to that checked. Then, one minute after the autopilot is unchanged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within  $\pm 25^\circ$ .

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		rudder	elevator	ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-10MO timer.

5. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of  $\pm 45^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $10^\circ$  in the direction opposite to that checked. Then, one minute after the auto-pilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within  $\pm 25^\circ$ .

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down



4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-2 gyro unit through an angle of  $\pm 5^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the H-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $10^\circ$  in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-2 unit in pitch within  $\pm 25^\circ$ .

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the H-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the H-3 gyro unit through an angle of  $\pm 45^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No. 4.

When stopping the H-3 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $10^\circ$  in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the H-3 unit in pitch within  $\pm 25^\circ$ .

Table No. 4

Channel	Direction of gyro unit turn	Direction of deflection		
		Rudder	Elevator	Ailerons
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

4. If two stop-watches are available check the programmed operation at a single switching-on of the II-18MO timer.

9. Check how the control surfaces are controlled by the free gyros: smoothly turn the II-2 gyro unit through an angle of  $\pm 45^\circ$  in yaw,  $\pm 25^\circ$  in pitch and  $\pm 40^\circ$  in roll. The control surfaces must smoothly, without jerks, deflect in accordance with Table No.4.

When stopping the II-2 gyro unit being deflected, the control surfaces and ailerons must not return to the neutral positions.

NOTE: Before checking the pitch control, turn the gyro unit in pitch, with the free gyros caged, through an angle of  $10^\circ$  in the direction opposite to that checked. Then, one minute after the autopilot is uncaged, check the control system. Perform a similar check with the unit turned in the opposite direction; proceed as specified in this note if the turn table does not permit turning the II-2 unit in pitch within  $\pm 25^\circ$ .

Table No.4

Channel	Direction of gyro unit turn	Direction of deflection		
		rudder	elevator	aileron
Direction	to the right	to the left	-	right aileron down
Pitch	up	-	down	-
Roll	to the right	-	-	right aileron down

10. Set the "MODE" selector switch in the "2-11 SIMULATOR" position. The "2-11 SIMULATOR" warning light must come on.

Switch on the "MODE" No. 1 switch on the control panel. The "MODE" No. 1 warning light must become illuminated. Then command No. 1 in test, the control surfaces may deflect from the position, occupied by them when the command is sent, through the angles within  $\pm 1.6^\circ$  (elevator and ailerons) and  $\pm 0.8^\circ$  (rudder).

Turn the "MODE" knob on the control panel to the "MODE" position. The rudder must, without jerks, deflect to the right and the right aileron - up. Set the "MODE" knob in the zero position; in this case the rudder and ailerons must move to the neutral position.

Repeat the check with the "MODE" knob turned to the "MODE" position.

Turn the "MODE" knob on the control panel to the "MODE" position. The elevator must, without jerks, deflect upwards. Set the "MODE" knob in the zero position; in this case the elevator must move to the zero position. Repeat the check with the "MODE" knob turned to the "MODE" position.

NOTE: The time, required for sending a signal of one polarity, should not exceed 15 sec.

11. Switch on the "MODE" No. 2 switch on the control panel. The "MODE" No. 2 warning light must become illuminated. Check how the control surfaces are controlled by the "MODE" and "MODE" pre-set units on the control panel in the same manner as when sending command No. 1; in this case, when setting the "MODE" and "MODE" knobs in the zero positions, the control surfaces must get move to the neutral position.

12. Set the "COGNITION No.1" and "COGNITION No.2" switches in the "OFF" position and the "COGNITION ROTATOR SWITCH" on the control panel - in the "COGNITION ROTATOR" position. Set the "POWER" switch of the [ ] control unit in the "OFF" position and if the autopilot has operated for more than 60 min. make an interval for not less than 30 min. to cool the [ ] gyro unit.

13. Switch on the [ ] control unit "COGNITION" switch. After the "COGNITION" warning light comes on (but not earlier than 3 min. after power is supplied) press the "UNCOGNITION" button on the control panel.

The "COGNITION" warning light must go out and the "UNCOGNITION" warning light must come on.

After 5 min., check the autopilot free gyro precession. The gyro rigidity should be so, that the control surfaces deflection from the neutral position for 5 min. would not exceed:

rudder  $\pm 1.25^\circ$   
 elevator  $\pm 2.5^\circ$   
 ailerons  $\pm 1.25^\circ$ .

When checking the gyro rigidity, the [ ] gyro unit must be in the horizontal position.

NOTE: The ailerons deflection depends also on the yaw free gyro precession (due to a signal picked up from the coordination potentiometer): therefore before determining the value of the roll free gyro precession, set the rudder in the neutral position by turning the [ ] gyro unit in yaw. In this case the ailerons deflection from the neutral position corresponds to the roll gyro precession.



14. Set the "POWER" switch on the H-I control panel in the "OFF" position. Disconnect the H-2 gyro unit plug connectors and remove the unit from the turn table.

15. Make entries about the autopilot checks performed in the "KC" missile Log-Book.

16. Install the H-2 unit in the missile and check the autopilot operation as follows (steps 17-24).

17. Connect plug connector No.36 of the ground test panel to the autopilot board check plug connector No.36 via the connecting cable, control panel plug connector No.12 through the connecting cable to plug connector No.12 of the missile wiring system having disconnected this plug connector from the K1-13W unit and connect plug connector No.45 through the control panel connecting cable to plug connector No.45 of the H-2 gyro unit having disconnected it from the missile electrical system.

Switch off all the switches on the control panel, supply power of  $28 \pm 0.5$  V d.c. to the missile electrical system and 26 volts to the "+" terminal of the control panel.

18. Switch on the "POWER" switch on the H-I control unit. The HAI-10A inverters must start operating. The "CAGED" and "BASES ZERO" warning lights on the control panel must become illuminated.

The control surfaces should be set in the neutral position. The indicator pointers on the control panel must be in the middle positions.

19. Switch on the "POWER" and "CHECK" switches on the control panel. Turn the "HOLDING" switch on the control panel.

14. Set the "POWER" switch on the [I-] control panel in the "OFF" position. Disconnect the H-2 gyro unit plug connectors and remove the unit from the turn table.

15. Make entries about the autopilot checks performed in the "KC" missile Log-Book.

16. Install the H-2 unit in the missile and check the autopilot operation as follows (steps 17-24).

17. Connect plug connector No.36 of the ground test panel to the autopilot board check plug connector No.36 via the connecting cable, control panel plug connector No.12 through the connecting cable to plug connector No.12 of the missile wiring system having disconnected this plug connector from the K1-1BM unit and connect plug connector No.45 through the control panel connecting cable to plug connector No.45 of the H-2 gyro unit having disconnected it from the missile electrical system.

Switch off all the switches on the control panel, supply power of  $28 \pm 0.5$  V d.c. to the missile electrical system and 26 volts to the "+" terminal of the control panel.

18. Switch on the "POWER" switch on the [I-] control unit. The HAI-1MA inverters must start operating. The "CAGED" and "BASES ZERO" warning lights on the control panel must become illuminated.

The control surfaces should be set in the neutral position.

The indicator pointers on the control panel must be in the middle positions.

19. Switch on the "POWER" and "CHECK" switches on the control panel. Turn the "RUDDER" knob on the control panel.

14. Set the "MODE" switch on the J-1 control panel in the "OFF" position. Disconnect the J-1 gyro unit plug, connectors and remove the unit from the turn table.

15. Make entries about the autopilot checks performed in the "KC" missile Log-Back.

16. Install the J-1 unit in the missile and check the autopilot operation as follows (steps 17-24).

17. Connect plug connector No.36 of the ground test panel to the autopilot board check plug connector No.36 via the connecting cable, control panel plug connector No.42 through the connecting cable to plug connector No.42 of the missile wiring system having disconnected this plug connector from the Ki-13M unit and connect plug connector No.43 through the control panel connecting cable to plug connector No.43 of the J-1 gyro unit having disconnected it from the missile electrical system.

Switch off all the switches on the control panel, supply power of  $28 \pm 0.5$  V d.c. to the missile electrical system and 26 volts to the "+" terminal of the control panel.

18. Switch on the "POWER" switch on the J-1 control unit. The HAP-1A inverters must start operating. The "CAGE" and "BASES ERROR" warning lights on the control panel must become illuminated.

The control surfaces should be set in the neutral position.

The indicator pointers on the control panel must be in the middle positions.

19. Switch on the "POWER" and "CHECK" switches on the control panel. Turn the "RUDDER" knob on the control panel.

The rudder and ailerons must deflect. Turn the "RUDDER" knob in the opposite direction. The rudder and ailerons must move in the opposite direction. Set the "RUDDER" knob in the zero position. Turn the "ELEVATOR" knob on the control panel. The elevator must deflect. Turn the "ELEVATOR" knob in the opposite direction. The elevator must deflect in the opposite direction. Set the "ELEVATOR" knob in the zero position.

Set the "CHECK" switch in the "OFF" position. Wait, till the control surfaces move to the neutral position and the "RUDDER DEFLECT" warning light comes on.

20. Press the "CHECK" button on the control panel. The "RUDDER DEFLECT" warning light must go out and the "CHECK" warning light must come on. Press the "CHECK" button and keep it pressed in both cases; in this case, the elevator must deflect up. Wait, till the elevator returns to the initial position.

21. Switch on the "CHECK" switch on the control panel. The "CHECK" warning light must come on. Turn the "RUDDER" knob on the control panel.

The rudder and ailerons must deflect.

Set the "RUDDER" knob in the zero position; in this case the rudder and ailerons must move to the neutral position. Repeat the check when turning the "RUDDER" knob in the opposite direction.

Turn the "ELEVATOR" knob on the control panel. The rudder must deflect. Set the "ELEVATOR" knob in the zero position; in this case the elevator must move to the neutral position. Repeat the check with the "ELEVATOR" knob turned in the opposite direction.



NOTE: It is permitted to check how the autopilot responds to control signals by means of No. 1 and No. 2 (tags 17-23) when sending the signals directly from the P-1 station. In this case do not disconnect plug connector No. 13 from the P-1-13P unit and use the "P-1" control panel instead of the ground test control panel.

#### 9. CALIBRATING THE AUTOPILOT - USE OF THE AUTOPILOT

The "P-1" autopilot output signals are not to be used when adjusting the all-terrain equipment of the "P-1" aircraft, 1st version, at the H-100 plant.

Given below are the instructions for calibrating the signals.

1. Install the "P-1" gyro unit on the "P-1" test table and connect the gyro unit plug connector (tag 17-23) to tag 13 (tags 1 and 2). Connect the "P-1" gyro unit plug connector No. 13 to the "P-1" gyro unit plug connector of the "P-1" control panel through the connecting cables.

Adjust the direction channel as follows:

2. At the "P-1" station, set the "P-1" switch of the control panel in the "P-1" position and switch on the "P-1" switch of the "P-1" control panel.

Connect the red terminal of the "P-1" connector (tag 17-23) to the "P-1" station, which is not more than 100 V. The resistance between the red terminal of the "P-1" connector and the red terminal of the "P-1" connector on the control panel is not less than 100 ohms. The resistance between the red terminal of the "P-1" connector and the "P-1" terminal on the control panel is not less than 100 ohms.



After the "CHECK" warning lights come on (but not earlier than 3 min. after power is supplied) press the "HYSTERIC" button.

3. Putting the "CHECK" switch on the "ON" position of the control panel in the "OFF" position and "ON" position. In both, we take on the voltage, output signal from the free gear and the servo unit feedback output signal by the voltmeter connected.

4. Measure as specified in step 1 with the gear unit turned about the vertical axis in the following succession:

to the right through the angles of:  $1^{\circ}$ ,  $2^{\circ}$ ,  $3^{\circ}$ ,  $4^{\circ}$ ,  $5^{\circ}$ ;

reverse travel:  $5^{\circ}$ ,  $4^{\circ}$ ,  $3^{\circ}$ ,  $2^{\circ}$ ,  $1^{\circ}$ ;

to the left through the angles of:  $1^{\circ}$ ,  $2^{\circ}$ ,  $3^{\circ}$ ,  $4^{\circ}$ ,  $5^{\circ}$ ;

reverse travel:  $5^{\circ}$ ,  $4^{\circ}$ ,  $3^{\circ}$ ,  $2^{\circ}$ ,  $1^{\circ}$ .

Before measuring with the gear unit turned to the left, cut off power supply to a short time using the "OFF" switch on the "CHECK" control panel and then send the "CHECK" command.

NOTE: Repeat as specified in steps 3 and 4 for not more than 1 min.

5. Put the "CHECK" switch on the "OFF" control panel in the "OFF" position.

After the check results in the table (at the end of section II).

Adjust the pitch channel as follows:

6. Switch on the "CHECK" switch on the "OFF" control panel. Connect the "+" terminal of the D.C. voltmeter, indi-

ated in step 2, to the  $\phi$  terminal on the control panel and  $\phi$  terminal of the voltmeter to the  $\phi$  terminal on the control panel.

After the  $\phi$  meter wiring is completed, close on (but not earlier than 10 sec after completion of the wiring) the  $\phi$  meter switch.

7. When closed, the  $\phi$  meter will indicate a value at the control panel in the  $\phi$  meter,  $\phi$  meter and  $\phi$  meter positions in turn, measure the  $\phi$  meter output signal from the  $\phi$  meter and  $\phi$  meter and  $\phi$  meter output signal of the voltmeter connected.

8. Measure as specified in step 7 with the  $\phi$  meter unit turned about the  $\phi$  meter axis as follows:

a. and  $\phi$  meter  $\phi$  meter  $\phi$  meter  $\phi$  meter  $\phi$  meter

reverse  $\phi$  meter  $\phi$  meter  $\phi$  meter  $\phi$  meter

close through to  $\phi$  meter  $\phi$  meter  $\phi$  meter  $\phi$  meter

reverse  $\phi$  meter  $\phi$  meter  $\phi$  meter  $\phi$  meter

Measure  $\phi$  meter with the  $\phi$  meter  $\phi$  meter  $\phi$  meter

10. Off power supply,  $\phi$  meter  $\phi$  meter  $\phi$  meter, the  $\phi$  meter switch on the  $\phi$  meter and  $\phi$  meter  $\phi$  meter  $\phi$  meter.

11. Measure as specified in steps 7 and 8, for not more than 10 min.

9. Set the  $\phi$  meter switch on the  $\phi$  meter control panel to the  $\phi$  meter position. Enter the measurements obtained in table.

10. With the  $\phi$  meter switch on the  $\phi$  meter control panel, connect the  $\phi$  terminal of the  $\phi$  meter, indicated in step 2, to the  $\phi$  terminal on the control panel and  $\phi$  terminal of the voltmeter to the  $\phi$  terminal on the control panel.

After the "B" light comes on (but not earlier than 3 min. after "A" is supplied), press the "MONITOR" button.

(1) has setting the "MONITOR" light on top of the control panel in the "MONITOR" position, and "TRIP" button in the "TRIP" position. The output signal of the "TRIP" button is the "TRIP" feedback output signal by the "TRIP" button.

(2) has setting the "MONITOR" light on top of the control panel in the "MONITOR" position.

to the "TRIP" button in the "TRIP" position, and the "TRIP" button in the "TRIP" position.

to the "TRIP" button in the "TRIP" position, and the "TRIP" button in the "TRIP" position.

Before releasing the "TRIP" button, the "TRIP" button in the "TRIP" position is the "TRIP" button in the "TRIP" position, and the "TRIP" button in the "TRIP" position.

After releasing the "TRIP" button, the "TRIP" button in the "TRIP" position is the "TRIP" button in the "TRIP" position.

(3) has setting the "MONITOR" light on top of the control panel in the "MONITOR" position, and the "TRIP" button in the "TRIP" position.

1. It is recommended that the following be done:

2. In the case of the missile, involved in continuing with the present test program, condition of the missile and its components should be checked at the time of the next flight and all with all the necessary units installed or such the gyro unit removed for the period for one year after the date of arrival at the point of destination.

3. The missile should be removed from the vehicle, as should be stored in the same condition.

4. The missile should be maintained according to the following schedule:

5. The missile should be stored with the main body in the same condition as when it was received, with the main body stored in the same condition as when it was received.

6. It is recommended to store the missile in the same condition as when it was received, with the main body stored in the same condition as when it was received. According to drawings 89.11.33.1 and 89.00.00.0003 for one year since the date of arrival at the point of destination.

7. The missile should be kept in the depot in the parking space prior to distribution in the missile for no more than 3 months after the date of acceptance by the Customer of the missile and provisions to be stored as specified in paragraph 1.

3. It is permitted to keep the M-10 autodialer in the "ON" position, with a temperature cover in the open air for 3 days.

4. The M-10 autodialer for storage or outfitting in steps in and out of the room in ventilation.

5. The M-10 autodialer must be equipped with the instruments to register the temperature and humidity in the room, and in the morning, in the evening, and in the middle of the day.

The results of the measurements must be entered in the log book.

6. The M-10 autodialer must be painted with a light color, white, pale yellow, or light blue. It must be placed in the room, not in the open air.

7. The M-10 autodialer must be placed in the room, not in the open air, and must be placed in the room, not in the open air.

8. The M-10 autodialer must be placed in the room, not in the open air, and must be placed in the room, not in the open air.

9. The M-10 autodialer must be placed in the room, not in the open air, and must be placed in the room, not in the open air.

Table No. 2

No.	Name	Unit	-10 per cent	Reg. No.
1				2
1.	U-10 autodialer	1		1000000
2.	U-10 autodialer	1		1000000
3.	U-10 autodialer	1		1000000
4.	U-10 autodialer	1		1000000

60

1	2	3	4	5
5. Radio equipment				
	PR. 1. 10. 11	1012-1		PR. 1. 10. 11
6. Fuse, glass		1012-1	5	1012-1
7. Fuse, glass		1012-1	10	1012-1
8. . . . . tool kit				1012-1
9. Shipping box for				1012-1
	1. 1. tool kit			1012-1
10. . . . . for				1012-1
	1. 1. tool kit			1012-1
11. . . . . (and 10-10-10)				1012-1
12. . . . . box				1012-1
13. . . . . meter				1012-1
14. . . . . (and 10-10-10)				1012-1
15. . . . . (and 10-10-10)				1012-1
16. . . . . (and 10-10-10)				1012-1
17. . . . . (and 10-10-10)				1012-1

The . . . . . set of spare parts, tools and devices, box manufactured at . . . . . ing to . . . . . 637.02.00.000, 637.02.00.000 and 637.02.00.000.

The . . . . . parts, tools and devices is packed and stored in . . . . . way . . . . . pilot.





When tested, it is permitted to change the frequency of switching in steps to the specified programmed operation and the output of the generator is changed during the first 30 minutes after the generator is switched on.

7. If the ALK-5B autopilots, taken for the next check in turn, are defective (corrosion included), check an additional number of the autopilots equal to the initial number of the autopilots to be checked.

If similar or some other defects are found in the autopilots checked, check all the ALK-5B of the autopilots included in the batch.

8. If during the check of an additional number of the ALK-5B autopilots (checked according to step 6), defects are not found, all the autopilots of the batch checked (defective excluded) can be admitted to a further storage.

The way of delivering the unsatisfactory reports and elimination of defects in the defective units is given in the "Instructions for making up the unsatisfactory reports".

9. During each periodic check enter the results of checks and information on all the operations performed during the inspection and checks in the certificate for the autopilot and its individual units.

10. The ALK-5B autopilot operating time, required for the periodic checks during storage, is determined by the time required for the checks specified by these instructions.

11. After the expiration of the ALK-5B autopilot storage life (for all specified storage conditions), check all the

autopilots as specified in these instructions for the periodic checks during storage.

The decision on the ANK-5B autopilot further storage and operation is adopted by the commission appointed by the organization commander.

#### 12. CHECKING THE ANK-5B AUTOPILOT OPERATION IN STORAGE WITHOUT REMOVING IT FROM THE "KC" MISSILE

1. After decompressing the "KC" missile and attaching the missile wings, remove the gyro unit from the missile.

Visually inspect all the autopilot units. Check that the units and cables outer surfaces are free from damage.

If corrosion is found on the autopilot units, proceed as outlined in steps 7-8, par. 20, these instructions.

2. Disconnect plug connectors No.32 and 33 from the missile wiring system and check the H-4 servo unit as indicated in par. 6 (steps 3-6): when checking the H-4 rudder servo unit, connect plug connector No.32 to the AL-1 panel, when checking the H-4 elevator servo unit, connect plug connector No.33 and when checking the H-4 ailerons servo unit connect plug connector No.35.

NOTE: During this check the H-4 servo unit outlet shaft direction of rotation indicated in

par. 6 (steps 3-6) corresponds to deflection of the control surface (ailerons) connected to the H-4 servo unit to be checked.

2. When checking at a temperature below  $0^{\circ}\text{C}$ , when storing the "KC" missile in the hangar), the H-4 servo units sensitivity must be:

with the "WINDING SELECTOR SWITCH" in "1", "2" and "3" positions...0.3-1.56 mA and in "4" position .....0.62-2.82 mA

When checking sensitivity use the H-1 panel with the H-70 test instruments at a temperature of  $-5^{\circ}\text{C}$  and with the M5-2 test instruments at a temperature of  $-40^{\circ}\text{C}$ .

3. Check the H-1 rudder and elevator servo units without disconnecting plug connectors Nos. 32 and 34 via plug connector 31 by means of the connecting cable. After checking the H-1 servo units, connect plug connectors Nos. 32 and No. 33 to the missile wiring system.

4. During the AIK-53 autopilot storage

under normal conditions the sensitivity of the II-4 servo units installed on a fixed base should be 0.5-1.2 mA with the "WINNING SELECTOR SWITCH" in "1", "2" and "3" positions and 0.95-2.22 mA - in the "4" position.

3. Disconnect plug connectors Nos 40 and 41 of the missile wiring system from the II-12A inverters and check the inverters operation as outlined in par. 6 (steps 8-10).

NOTE: When checking the IIA-12A inverters at a temperature below 0°C (when storing the "KC" missile in the hangar) use the II-5 panel with the IIA-70 and II-70 test instruments only to check rotation of the II-5 panel gyro motors without measuring the input and output current and the voltage generated by the inverter.

4. Install the II-5 gyro unit on the IIA-5 turn table and connect the gyro unit plug connectors as indicated in par. 8 (steps 3 and 4).

5. Check the autopilot operation as specified in par. 8 (steps 5-12).

NOTES: When checking at a temperature below 0°C (when storing the "KC" missile in the hangar):  
a) apply the "UNCAGING" command, 6 min. after power is supplied;



b) the elevator must return to the initial position 40-43 sec. after the "H-18MC START" button is pressed.

6. Check the time required for the yaw and pitch gyro bases to match in the zero position as follows: switch on the "POWER" switch on the H-I control panel. After the "BASES ZERO" warning lights come on, set the "POWER SELECTOR SWITCH" in the "BOARD CHECK" position and switch on the "CHECK" switch. The "BOARD CHECK" and "CHECK" warning lights must come on.

Fully turn the "RUDDER" knob on the control panel to the "RIGHT". The rudder must smoothly, without jerks, deflect to the right and the right aileron must deflect up. Wait for 7 min. Set the "RUDDER" knob in the zero position and the "CHECK" switch in the "OFF" position. The rudder must move to the neutral position. After 4.5-6.5 min. the ailerons must move to the neutral position and the "BASES ZERO" warning lights must come on.

Switch on the "CHECK" switch and repeat the check with the "RUDDER" knob turned to the "LEFT".

After the "BASES ZERO" warning lights come on switch on the "CHECK" switch and fully turn the "ELEVATOR" knob upward.

The elevator must smoothly, without jerks deflect up. Make an interval for 4 min. Set the "ELEVATOR" knob in the zero position and the "CHECK" switch in the "OFF" position. The elevator must move to the neutral position. After 2-3.5 min the "BASES ZERO" warning light must come on.

Switch on the "CHECK" switch and repeat the check with the "ELEVATOR" knob turned to the "DOWN" position.

Check the time required for the bases to match at a supply voltage of 26 V.

7. Check the autopilot transmission ratios as indicated in par. 19, step 6.

NOTES: 1. When checking at a temperature below 0°C (when storing the "KC" missile in the hangar):

- a) make an interval for 7.5 min. when sending the "DIRECTION" signal; in this case the "BASES ZERO" warning lights must come on 4-7 min. after the "CHECK" command is removed.
- b) when sending the "PITCH" signal, make an interval for 5 min.; in this case the "BASES ZERO" warning lights must come on 1.5-4.0 min. after the "CHECK" command is removed.
- c) do not check the autopilot transmission ratios.

2. When storing the "KC" missiles in the hangar, check the time required for the bases to match once in 6 months.

8. Set the "POWER" switch on the II-1 control panel in the "OFF" position. Disconnect the II-2 gyro unit plug connectors and remove the gyro unit from the turn table. Install the II-2 gyro unit in the "KC" missile and check the autopilot operation using the IHK ground test control panel as outlined in par. 8 (steps 17-24).

9. Enter the results of checks and time required for checking the units and autopilot set energized in the certificate of the individual units and AHK-5B autopilot set.

10. It is permitted to check the H-4 gyro unit in a reference or any other serviceable autopilot set system as indicated in par. 6 (steps 14-21).

In this case do not check the autopilot stored in the set but check the H-4 servo unit, H-1110 timer and HAF-10A inverter which are stored in the missile as follows:

- a) H-4 servo units - as outlined in par. 6 (steps 3-6 ;
- b) H-1110 timers - as outlined in steps 11-13, this par.
- c) HAF-10A inverters - as outlined in par. 6 (steps 8-10)

11. Check the H-1110 timers as follows:

disconnect plug connector No.33 from the missile wiring system. Set the "TIMER" switch of the H-1 panel in the "OFF" position.

Supply power of 26 V. d.c. to the control panel. Connect the H-1110 timer plug connector No.33 to the panel via the connecting cable. Set the "TIMER" selector switch in the "H-1110" position and the "TIMER SELECTOR SWITCH" in the "ON" position.

12. Switch on the "POWER" and "FEEDBACK" switches. The elevator must rise to the initial position ( $2.5^{\circ}$ - $3^{\circ}$  Up from the geometric neutral position).

Switch on the "H-1110 START" switch and simultaneously start the stop-watch. 2-3 sec. after the "H-1110 START" switch is on the elevators must deflect through an angle of  $9$ - $9.5^{\circ}$  Up from the initial position ( $12$ - $12.5^{\circ}$  Up from the geometric neutral position) and 40-42 sec. after the switch is on the elevator must return to the required initial position.



Start the H-18MO timer twice. When starting the timer for the first time, check the elevator angle of deflection and the program starting time (2-3 sec.), to do this, start the stop-watch when the elevator deflects upward. When starting the timer for the second time, check the time of the program completion (40-42 sec.): to do this, stop the stop-watch when the elevator begins moving to the initial position. The second check is performed 20-30 seconds after the first actuation of the program is over.

NOTE: 1. It is permitted to adjust the H-18MO timer rheostat if the elevator fails to deflect through an angle of  $12^{\circ}$ - $12.5^{\circ}$  up from the geometric neutral position.

2. If it is necessary to check the programmed operation for the third and subsequent times, bear in mind, that the H-18MO timer operating duty is intermittent consisting of 6 cycles followed by a complete cooling. A cycle implies one actuation of the program.

3. If two stop-watches are available, check the program at a single switching-on of the H-18MO timer.

12. Set the "POWER" switch on the panel in the "OFF" position. Disconnect the panel from the H-18MO timer plug connector and connect this plug connector to the missile wiring system.

### 13. CHECKING THE ANA-5B AUTOPILOT OPERATION IN STORAGE WITH SOME UNITS REMOVED FROM THE MISSILE

1. After the ANA-5B missile is depreserved and its wings are attached, visually inspect the H-1 control panel, H-1 servo units, H-10M timer and HAP-1A inverters which are stored installed in the missile. Open the case with the H-1 gyro unit as indicated in par. 3. and visually inspect the unit. Check that the units outer surfaces and cables are free from damage.

If corrosion is detected, proceed as outlined in steps 7-8, par. 20.

2. Check the ANA-5B autopilot as indicated in par. 12 without checking the autopilot set by means of the TBM ground test control panel.

After checking the H-1 gyro unit, pack it in a metal case as indicated in par. 4 (without packing the H-1 control panel). Enter the results of checks and time required for checking the units and autopilot set energized in the certificates for the individual units and ANA-5B autopilot set.

### 14. CHECKING THE ANA-5B AUTOPILOT WHEN STORING IT PACKED IN TBM

1. Inspect the packing cases. Check the cases for presence of seals and for freedom from damages. Unpack the autopilot units as indicated in par. 3. Inspect all the units. Check the outer surfaces of the units and cables for freedom from damages.



71

# 13. CHECKING THE ANA-5B AUTOPILOT OPERATION IN STORAGE WITH SOME UNITS REMOVED FROM THE MISSILE

1. After the "B" missile is deprotected and its wings are attached, visually inspect the H-1 control panel, H-4 servo units, H-10M timer and HAP-1A inverters which are stored installed in the missile. Open the case with the H-2 gyro unit as indicated in par. 3. and visually inspect the unit. Check that the units outer surfaces and cables are free from damage.

If corrosion is detected, proceed as outlined in steps 7-8, par. 10.

2. Check the ANA-5B autopilot as indicated in par. 12 without checking the autopilot set by means of the TENK ground test control panel.

After checking the H-2 gyro unit, pack it in a metal case as indicated in par. 4 (without packing the H-1 control panel). Enter the results of checks and time required for checking the units and autopilot set energized in the certificates for the individual units and ANA-5B autopilot set.

## 14. CHECKING THE ANA-5B AUTOPILOT WHEN STORING IT PACKED IN TAP

1. Inspect the packing cases. Check the cases for presence of seals and for freedom from damages. Unpack the autopilot units as indicated in par. 3. Inspect all the units. Check the outer surfaces of the units and cables for freedom from damages.

If corrosion is found on the autopilot units, proceed as outlined in steps 7-8, par. 20, these Instructions.

2. Check the H-4 servo units as indicated in par. 6 (steps 3-6); in this case, under normal conditions the sensitivity of the H-4 servo units installed on a fixed base is equal to 0.5-1.2 mA with the "BINDING SELECTOR SWITCH" in "1", "2" and "3" positions and 0.95-2.22 mA in the "4" position.

3. Check the HAI-12A inverters as indicated in par. 6 (steps 8-10).

4. Check the autopilot set operation as outlined in par. 6 (steps 14-23) and time required for the bases to match as outlined in par. 12 (step 6).

After the check is completed, pack the autopilot units in the metal case as indicated in par. 1 and enter the results of checks and time required for checking the units and autopilot set energized in the certificates for the individual units and set of the ABB-58 autopilot.

#### 15. PROCEDURE OF REPLACING THE ABB-58 AUTOPILOT INDIVIDUAL UNIT AND COMPONENTS

1. If during the ABB-58 autopilot operation and storage defects are found, replace the H-1, H-2, H-4, H-18MO units, H2-1, H2-2, H2-3, H2-4, H2-6AM, components, polarized relay and trimming rheostat in the H-2 gyro unit, H2-1MO component in the H-4 servo unit and H-4-1MO component polarized relay.

2. Remove and install the units to be replaced in the "K" missile in accordance with the "Maintenance and Operating Instructions for the "K" Winged Missile", Book I.

3. Replace the H4-IMO component in the H-4 servo unit as follows:

remove the seal and unscrew by socket wrench two studs attaching the defective H4-IMO component to the H-4 servo unit and remove the component from the unit. Install a new H4-IMO component on the H-4 servo unit.

Carefully insert two attaching studs of the component into the holes in the component casing and tighten the studs by the socket wrench; tighten the studs alternately, and evenly, secure the studs with a locking wire and seal it with the using organization seal.

4. Replace the PHO polarized relay in the H-2 gyro unit as follows:

Unscrew 6 screws attaching the H-2 gyro unit side cover. Unscrew 4 screws attaching the defective relay to the H2-6M (H2-6AM) component and remove the relay out of the unit. Carefully install (without touching the electric wires) a new polarized relay in the H2-6M (H2-6MA) component and tighten the relay attaching screws; tighten the screws alternately and evenly. Secure the screws with AK-20 nitro glue according to instructions No. MB-621 (See the appendix). Screw the H-2 unit side cover, in this case safety the screws with AK-20 nitro glue according to instructions No. MB-621.

5. Replace the trimming rheostats as follows:

Remove the H-2 gyro unit lower cover.

Unsolder the wires from the trimming rheostat to be replaced and measure the resistance set for the given rheostat.

3. Replace the H-110 component in the H-1 servo unit as follows:

remove the seal and unscrew by socket wrench two studs attaching the defective H-110 component to the H-1 servo unit and remove the component from the unit. Install a new H-110 component on the H-1 servo unit.

Carefully insert two attaching studs of the component into the holes in the component casing and tighten the studs by the socket wrench; tighten the studs alternately, and evenly, secure the studs with a locking wire and seal it with the using organization seal.

4. Replace the H-10 polarized relay in the H-2 gyro unit as follows:

Unscrew 6 screws attaching the H-2 gyro unit side cover. Unscrew 4 screws attaching the defective relay to the H-2-10 (H-2-10A) component and remove the relay out of the unit. Carefully install (without touching the electric wires) a new polarized relay in the H-2-10 (H-2-10A) component and tighten the relay attaching screws; tighten the screws alternately and evenly. Secure the screws with AK-20 nitro glue according to instructions No. KB-21 (see the appendix). Screw the H-2 unit side cover, in this case safety the screws with AK-20 nitro glue according to instructions No. KB-21.

5. Replace the trimming rheostats as follows:

Remove the H-1 gyro unit lower cover.

Unsolder the wires from the trimming rheostat to be replaced and measure the resistance set for the given rheostat.



3. Remove the  $\text{H-10}$  component in the  $\text{H-10}$  servo unit as follows:

Remove the seal and unscrew the socket wrench the studs attaching the  $\text{H-10}$  component to the  $\text{H-10}$  servo unit and remove the component from the unit. Install a new  $\text{H-10}$  component in the  $\text{H-10}$  servo unit.

Carefully insert the standing studs of the component into the hole in the component using the tightener the studs by the socket wrench; tighten the studs alternately, and evenly, connect the studs with a locking wire and seal it with the using ergonol also seal.

4. Replace the  $\text{H-10}$  polarized relay in the  $\text{H-10}$  gyro unit as follows:

Unscrew the  $\text{H-10}$  unit side cover. Unscrew the  $\text{H-10}$  unit the defective relay to the  $\text{H-10}$  ( $\text{H-10}$ ) component and remove the relay out of the unit. Carefully install the  $\text{H-10}$  (touching the electric wires) a new polarized relay in the  $\text{H-10}$  ( $\text{H-10}$ ) component and tighten the relay attaching screws; tighten the screws alternately and evenly. Seal the screws with  $\text{H-10}$  nitro glue according to instructions No.  $\text{H-10}$  (see the appendix). Screw the  $\text{H-10}$  unit side cover, in this case safety the screws with  $\text{H-10}$  nitro glue according to instructions No.  $\text{H-10}$ .

5. To tune the trimming rheostats as follows:

Remove the  $\text{H-10}$  unit lower cover.

Unscrew the wires from the trimming rheostat to be replaced and measure the resistance set for the given rheostat.



72

2. Article 1 of the Agreement in the 1941 version and as follows:

Remove the 1/2" Allen wrench. Use socket wrench to studs attaching the actuator to the component to the A- servo unit and remove the actuator from the servo. Install a new 1/2" Allen wrench to the actuator unit.

approximately 1000 to 1500 attending students of the component  
into 1000 to 1500 to 2000 per school, totaling 100,000 to 150,000  
by the 1970's. But as the 1970's began, the student population, and  
eventually, the number of schools, began to grow and would reach 100,000  
the 1980's. (Exhibit 1, page 2)

4. The above information was obtained from the [redacted] file  
unit on [redacted].

Insert the [redacted] into the [redacted] unit side cover.  
Insert the [redacted] into the [redacted] relay to the [redacted] (M-11) [redacted] [redacted] the relay out of the unit.  
Carefully install [redacted] touching the electric wires) a new [redacted] [redacted] (M-11) component and tighten the [redacted] retaining screws. Tighten the screws alternately [redacted] the screws with M-11 nitro blue [redacted] [redacted] (see the appendix) [redacted] the [redacted] cover, in this case, safety the screws [redacted] [redacted] according to instructions [redacted].

5. The following Army statistics are follows:

MILITARY: ... UNIT TOWER CONTROL.

Unsat. or the value from the trimming rheostat to be replaced by the value of the resistance set for the given rheostat

73

2. Remove the ~~10-10~~ component in the ~~10-10~~ servo unit as follows:

Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ servo unit. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ servo unit.

Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ servo unit. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ servo unit. Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ servo unit. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ servo unit.

3. Remove the ~~10-10~~ component in the ~~10-10~~ gyro unit as follows:

Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ gyro unit. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ gyro unit. Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ gyro unit. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ gyro unit. Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ gyro unit. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ gyro unit. Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ gyro unit. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ gyro unit.

4. Remove the ~~10-10~~ component as follows:

Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ component. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ component.

5. Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ component. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ component. Remove the ~~10-10~~ component by using a socket wrench to remove the two studs which hold the ~~10-10~~ component to the ~~10-10~~ component. Remove the ~~10-10~~ component from the unit. Install a new ~~10-10~~ component in the ~~10-10~~ component.

5. Remove the component in the servo unit as follows:

Remove the component by using a socket wrench the studs attaching the component to the servo unit and remove the component from the unit. Install a new component in the servo unit.

Insert the mounting studs of the component into the servo unit and secure using and tighten the studs by the socket wrench applied the studs alternately, one evenly, and secure with a locking wire and seal it with the using of the seal.

6. Remove the component in the gyro unit as follows:

Remove the component by the gyro unit side cover. Insert the component into the defective relay to the gyro unit and remove the relay out of the unit. Carefully (without touching the electric wires) a new component (type 11-24) (11-24A) component and tighten the attaching screws; tighten the screws alternately and use the screws with 11-24 nitro glue and use the instructions re. 11-24 (see the appendix). Remove the side cover, in this case safety the screws that are given according to instructions in the appendix.

7. Replace the trimming rheostats as follows:

Remove the unit lower cover.

Unscrew the trimmer rheostat to be replaced and replace the resistance set for the given rheostat.

72

2. Items of the said component in the 1-1 servo unit as follows:

Remove the nut and washer by socket wrench; two studs  
attach the bracket to the component to the 5-1 servo  
unit and remove the bracket from the unit. Install a new  
5-1 bracket onto the 5-1 servo unit.

over the top of the standing stumps of the component  
into the ground. When the stumps were being cut, lighted the stumps  
by the use of a small amount of kerosene and the stumps ultimately, now  
standing, are covered with a covering wire and seal it with  
the wire. The wire is sealed with the wire.

- The "B-1" was obtained only in the "B-1" group  
unit, no other.

Remove the cover by turning the 1/4" hex unit side cover.  
Insert the 1/4" hex unit side cover. Effective relay to the 1/4" hex  
1/4" hex unit side cover. Remove the relay out of the unit.  
Remove the 1/4" hex unit side cover. Touching the electric wires, a  
new 1/4" hex unit side cover. (1/4" hex unit side cover) component  
and the 1/4" hex unit side cover. Tighten the screws  
down the 1/4" hex unit side cover. Tighten the screws with 1/4" hex unit side  
cover. Tighten the screws with 1/4" hex unit side cover. See the appendix,  
Tighten the screws with 1/4" hex unit side cover, in this case safety the  
screws with 1/4" hex unit side cover. According to instructions  
do the same.

2. The following information is to be followed:

... TOWER CORP.

One must also check the isolating rheostat to be replaced to make sure the resistance set for the given rheostat

72

2.  $\alpha$  is a constant in the interval  $(0, 1)$ .

Remove the old and broken air cooler which the studs  
belonged to. Remove the old component to the A/C servo  
unit and replace with a new one. Install a new  
A/C servo unit in the A/C servo unit.

Continuing down the following studs of the component into the hole in the rear column using one tighten the studs by the 1/2 inch increments together the studs alternately, and finally, secure the studs with a locking wire and seal it with the seal. (Illustration 100 seal).

and the 11 columned entry in the 1-4 gyro  
unit are followed:

Uncover the relay by removing the 10-1 wire unit side cover. Uncover the relay and then the defective relay to the 10-14 (10-14) component and remove the relay out of the unit. (Carefully do not touch the electric wires) a new 10-14 relay to the 10-14 (10-14) component and tighten the 10-14 by attaching screws. tighten the screws alternately and evenly. Tighten the screws with 10-10 nitro glue and follow instructions re. 10-14 (see the appendix) before the 10-14 unit cover, in this case safety the screws and 10-14 (10-14) according to instructions

5. Prepare the following Sheostats as follows:

7. REMOVE THE LOWER COVER.

Unsolder the wire from the trimming rheostat to be replaced and adjust the resistance set for the given rheostat



Unscrew the screws attaching the plate with the trimming rheostat to the servo unit casing. Unscrew the nut attaching the rheostat to be removed and remove the rheostat.

Install new rheostat in place. Secure the rheostat by a screw with a nut (place a washer under the nut).

Install the rheostat without any cant, the adjusting screws must have a clearance between the screw head and hole in the upper plate.

Set the rheostat resistance equal to that measured before the rheostat is replaced.

Align the wire to the trimming rheostat. Attach the plate with the trimming rheostat to the servo unit casing using the screws (place a washer under the screw heads).

Align the adjusting screws and nuts with X-39 with the according to the instructions in Fig. 1-13.

6. After the servo unit is replaced, proceed as follows:

a) check the servo unit operation as outlined in Fig. 1-13, part 1. Set the auto pilot unit in the servo unit in the missile and the servo unit received from the manufacturer as outlined in Fig. 1-13, part 1. Set the auto pilot unit stored in the servo unit.

b) check the auto pilot transmission ratio as described below:

NOTE: 1. Check the auto pilot transmission ratio at a temperature of 20 to 30°C.

2. The ratio of checking the auto pilot transmission ratio refers to storage of the servo unit installed in the missile.

If the autopilots are packed in the cases the methods of checking the autopilot transmission ratios are the same; in this case the amount of the H-4 servo units outlet shafts turn must be:

With the H-3 gyro unit deviated in yaw; direction control surface (rudder) -  $2.25-2.75^{\circ}$  (instead of  $2.1-2.9^{\circ}$ )  
roll control surface (aileron)  $4-5^{\circ}$  (instead of  $3.8-5.3$ )

With the H-2 gyro unit deviated in pitch:

elevator -  $4.5-5.5^{\circ}$  (instead of  $4.3-5.8$ )

With the H-1 gyro unit deviated in roll:

roll control surface (aileron) -  $4.9-5.5^{\circ}$  (instead of  $4.3-5.8$ ).

2. Check the autopilot transmission ratios at a power supply of 26 V d.c.

Check the rudder transmission ratio and the angle of the H-4 aileron servo unit turn controlled by the coordination signals as follows:

After sending the "YAW" command, turn the H-2 gyro unit in yaw through an angle of  $5^{\circ}$ . The rudder must deflect  $2.1-2.9^{\circ}$  and ailerons - through an angle of  $3.8-5.3^{\circ}$ .

Turn the H-2 unit in opposite direction through an angle of  $5^{\circ}$  in yaw. The rudder and ailerons must deflect respectively through the angles of  $2.1-2.9^{\circ}$  and  $3.8-5.3^{\circ}$  to the opposite side.

- NOTES:
1. The difference in the ailerons deflection in both directions must not exceed  $0.5^{\circ}$ .
  2. If the rudder deflection does not meet the required value, adjust the H-2 gyro unit rheostat No.3 connected in the yaw free gyro circuit. To do this, remove the lower cover of the H-2 gyro unit and rotate rheostat No.3 screw till the required deflection of the rudder is obtained. It is permitted to adjust the rheostat No.3 within  $290 \pm 29$  ohms. The place of the bridge connection for checking the resistance value is given in Table No.3
  3. If the ailerons deflection does not meet the required value, adjust rheostat No.12 connected in the coordination signal circuit. It is permitted to adjust rheostat No.12 within the range of  $300 \pm 30$  ohms.

Check the elevator transmission ratio as follows:  
after sending the "UNWAGING" command, turn the H-2 gyro unit in pitch through an angle of  $5^{\circ}$ . The elevator must deflect  $4.3-5.8^{\circ}$ . Turn the H-2 gyro unit in pitch through an angle of  $5^{\circ}$  in the opposite direction. The elevator must deflect through an angle of  $4.3-5.8^{\circ}$  in the opposite side.

NOTE: If the elevator deflection does not meet the required value, adjust rheostat No.5 connected in the pitch free gyro circuit. It is permitted to adjust rheostat No.5 within the range of  $115 \pm 11.5$  ohms.

Check the ailerons transmission ratio as follows:

After sending the "UNCAGING" command, turn the H-2 gyro unit in roll through an angle of  $10^\circ$ . The ailerons must deflect  $4.3-5.8^\circ$ .

Turn the H-2 gyro unit in roll through an angle of  $10^\circ$  in the opposite direction.

The aileron must deflect  $4.3-5.8^\circ$  in the opposite side.

NOTE: If the ailerons deflection does not meet the required value, adjust rheostat No.10 connected in the roll feedback circuit. It is permitted to adjust rheostat No.10 within the range of  $100 \pm 5$  ohms.

Table No.6

Resistor No.	Name of electric circuit	Pins across which measurement is performed.	Resistance ohms
3	Yaw free gyro signal circuit	31/3-42/2	$290 \pm 29$
5	Pitch free gyro signal circuit	31/22-42/4	$115 \pm 11.5$
10	Roll feedback signal circuit	35/11-35/13	$100 \pm 5$
12	Bank coordination signal circuit	35/7-35/8	$300 \pm 30$

- NOTES:
1. Check resistance by a d.c. bridge having the degree of precision not less than 2.5.
  2. The plug connectors pins are arbitrarily designated: the numerator shows the number of the plug connector and the denominator - the number of the plug connector pin.
  3. When checking, connect the plugs to the units mating receptacles. Connect the measuring bridge wires to the pins (sockets) of the plug connected.
  4. Pins 31/3-42/3; 31/22-42/4 refer to H-2 gyro unit and are manufactured according to a special order with connector plug No.42. Measure resistors 2,5 of the production units across their contacts.
  7. After replacing the H-4 unit or H-1-IMO component (or polarized relay in this component) check as outlined in par. 6 (steps 3-6) and check transmission ratio of the corresponding channel of the autopilot as described in step 6, this paragraph).
  8. After replacing the H-1-IMO timer check as indicated in step 8, par. 3 (when storing the H-1-IMO timer in the missile) or as in step 17, par. 6 (when storing the timer in a packing case).
  9. After replacing the H-1 control panel, check as outlined in steps 2-9, par. 3 (when storing the panel in the missile) or as in steps 13-14, par. 6 (when storing the panel in a packing case).



10. After the П2-6M, П2-6AM components or PHC polarized relay in the П2 gyro unit are replaced, check as specified in steps 7, 10 and 11, par. 3 (when storing all the autopilot units installed in the "22" missile or with the П-2 gyro unit removed from the missile) or as in steps 10, 12 and 13, par. 6 (when storing the autopilot units in packing cases).

11. After replacing the П2-6 or PHC component in the П-2 gyro unit, check as indicated in steps 7, 10 and 11, par. 3 (when storing all the autopilot units installed in the "22" missile or with the П-2 gyro unit removed from the missile) or as in steps 10, 12 and 13, par. 6 (when storing the autopilot units in packing cases) and check the transmission ratio of the corresponding channel as outlined in step 6, this paragraph.

12. After replacing the П2-6 component in the П-2 gyro unit, check as indicated in steps 7, 9, 12, par. 3 (when storing all the autopilot units installed in the "22" missile or with the П-2 unit removed from the missile) or as in steps 14, 15, 22, par. 6 (when storing the autopilot in packing cases) and check the Allison collection transmission ratio as indicated in step 6, this paragraph.

13. After replacing the П2-6 component in the П-2 gyro unit, check as indicated in step 7, par. 3 (when storing all the autopilot units installed in the missile or with the П-2 gyro unit removed from the missile) or as in step 15, par. 6 (when storing the autopilot units in packing cases).

14. After adjusting trimming racestate No. 3, 5, 10 and 12, check the transmission ratio of the corresponding channel as outlined in step 6, par. 12.

required under the contract for the A-1H-5B autopilot individual to report.

# SECTION IV

## 1. PRE-FLIGHT CHECKS

### 1.1. CHECKS OF THE AIRCRAFT AUTOPILOT

1. Perform a separate check of the AIR-38 autopilot during the pre-flight preparation as outlined below, bear in mind that:

a) the autopilot is stored (installed) and the "P" missile must not be subjected to preliminary checks;

b) the "P" missile, being in individual units are stored being removed from the "P" missile, must be preliminarily checked, irrespective of the time of the previous periodic checks, at least once per day, and after that the "P" missile unit is to be checked in the missile.

c) the autopilot is stored in packing cases must be preliminarily checked, irrespective of the time of the previous periodic checks, at least once per day, and after that the autopilot unit must be installed in the missile.

2. During the check, place the "P" missile in the "P" missile unit on an airfield cart.

3. Connect plug connector No. 16 to the ground of the central panel via the connecting cable to the autopilot (check plug connector No. 16 and plug connector No. 17) and panel through the connecting cable - to the missile wiring system plug connector No. 12, having disconnected this plug connector from the "P-15" unit.

will be the same as the power of 2048. The power of 2048 is the same as the power of 2048.

4. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.

The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.

5. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.

6. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.

7. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.

8. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.

9. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.

10. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048. The power of 2048 is the same as the power of 2048.





3. If two stop-watches are available, check the program at a single switching-on of the 1-1000 timer.

4. Check as outlined in this step and step 11, this paragraph during the first 30 minutes after the autoriset is set.

5. When checking the temperature below the elevator must return to the initial position after the "1-1000" button is pressed.

6. Inclined the missile by the wire to the right. The right aileron must deflect down, incline the missile to the left. The right aileron must deflect up, set the missile in the original position in this case, the ailerons must be set in the neutral position.

7. Switch on the "1-1000" No. 12 switch on the control panel. The "1-1000" No. 12 warning light must come on. Turn the "1-1000" knob on the panel. The rudder and ailerons must deflect. Set the "1-1000" knob in the zero position; in this case the rudder and ailerons must move to the neutral position. Repeat the check with the "1-1000" knob turned in the opposite direction.

Turn the "1-1000" knob on the panel. The elevator must deflect. Set the "1-1000" knob in the zero position, the elevator must move to the neutral position. Repeat the check with the "1-1000" knob turned in the opposite direction.

Note: Time, required for sending a signal of one pulse, must not exceed 10 seconds.

10. Switch on the "POWER" No. 2 switch on the panel. The "COMMAN" No. 1 warning light must come on. Check how the control surfaces are controlled by the "GIMBAL" and "ELEVATOR" pre-set knobs on the panel in the same way as when sending commands No. 1: In this case when setting the "GIMBAL" and "ELEVATOR" knobs in the zero positions, the control surfaces and ailerons must not deflect to the neutral position. Set the "POWER", "COMMAN" No. 1 and "ELEVATOR" No. 2 switches on the panel in the "OFF" position.

11. Using the "OFF" switch on the control panel cut off power supply for a short time. The "COMMAN" warning light must come on, the control surfaces and ailerons must occupy the neutral position and the "OFF" warning light must become illuminated.

Press the "BURNING" button on the control panel. The "COMMAN" warning light must go out. After 5 minutes check the free gyro procession. The gyro rigidity must be so that the control surfaces deflection for 5 minutes would not exceed:

rudder  $\pm 1.25^\circ$

elevator  $\pm 2.5^\circ$

ailerons  $\pm 1.25^\circ$ .

NOTE: The ailerons deflection also depends on the free gyro procession due to a signal picked up from the operational potentiometer. Therefore, before leaving during the roll free gyro procession, switch on the "GIMBAL" switch on the panel and send the direction control signal. On low values and such a potentiometer the signal could move to the neutral position.

after that quickly remove the control signal. In this case the deflection of ailerons from the neutral position will correspond to the roll gyro precession.

12. Put the "OFF" switch on the "P-1" control panel in the "OFF" position. Disconnect the ground test control panel from plug connectors No. 36 and 42.

Connect the missile wiring system plug connector No. 42 to the "P-1" unit.

Re-energize the missile electrical system.

17. "OFF" switch on the "P-1" control panel in the "OFF" position.

1. To test the "P-1" unit, first put the "P-1" station separate system, connect the ground test control panel plug connector No. 42, to the "P-1" board, check plug connector No. 36 with the "P-1" station.

When the "P-1" station is connected to the panel and supply power of 28 + 0.5 V to the missile electrical system.

2. Put the "P-1" station. The "P-1" station warning light on the "P-1" board will come on. Wait till zero control currents are sent from the station to the autopilot (check by using the "P-1" panel).

Switch on the "P-1" switch on the "P-1" control panel. The "P-1" station warning light on the panel must come on. Press the "P-1" button.

3. Put the "P-1" station in regime

When sending the "RIGHT" signal, the rudder must deflect to the right and the right aileron - up. When removing the signal the rudder and ailerons must move to the neutral position.

When sending the "LEFT" signal, the rudder must deflect to the left and the right aileron - down. When removing the signal the rudder and ailerons must move to the neutral position. When sending the "UP" signal, the elevator must deflect upward. When removing the signal, the elevator must move to the zero position.

When sending the "DOWN" signal, the elevator must deflect down. When removing the signal, the elevator must move to the zero position.

Note: Time, required for sending a signal of one polarity must not exceed 1/2 seconds.

4. Press the "TEST" switch on the H-I control panel out off, very briefly for a short time. The "CHECK" warning light must come on.

Wait, till the control surfaces are set in the neutral position and the "CHECK" warning light becomes illuminated. Set the "TEST" switch on the H-I control panel in the "OFF" position.

5. Send command No. 2 from the H-I station. The "WARNING No. 2" warning light on the panel must come on. Wait till zero control currents are supplied from the station to the autopilot.

Switch on the "H-I" switch on the H-I control panel. The "CHECK" and "B.I. STOP" warning lights on the panel must come on. After 3 minutes press the "UNLOADING" button.

Send control signals in regime "B" from the K-1M station to the autopilot.

The direction of the control surfaces deflection must be the same as in step 3. When removing control signals the control surfaces must not move to the neutral position.

6. De-energize the autopilot as indicated in step 4. Disconnect the ground test control panel from plug connector No.36.

## SECTION V

## AP-33 AUTOPILOT TEST BEFORE TAKE-OFF

18. TESTING THE AP-33 AUTOPILOT BY USING THE CARRIER-  
- AIRCRAFT EQUIPMENT

1. Connect the ground test control panel plug connector No.38 to the autopilot board check plug connector No.37 through the connecting cable.

Check that the "AP-33" switches on the E-I control panel and "I-13M" unit are in the "ON" position.

2. Switch on the "AP-33 POWER" and "AP-33 E-1" switches on the bombardier control panel in the front cabin. The "AP-33 E-1" warning light on the bombardier's panel comes on.

3. Check the autopilot operation using the ground test control panel:

a) switch on the "ELEVATOR" switch on the E-I control panel. The "ELEVATOR" and "ELEVATOR ZERO" warning lights on the panel must come on.

b) after 2 minutes, press the "UNCAUTION" button on the panel.

The "ELEVATOR" warning light must go out.

Press the "ELEVATOR START" button on the panel and keep it pressed for 5-10 seconds. The elevator must deflect  $9-9.5^\circ$  up from the initial position ( $12-12.5^\circ$  up from the geometric neutral position). Wait, till the elevator returns to the initial position.



c) switch on the "AL" switch on the panel, and the control signals by turning the "RUDDER" and "ELEVATOR" pre-set units knobs. When sending the direction signal the rudder and ailerons must deflect and when sending the pitch signal the elevator must deflect. At the "AL" switch on the panel in the "OFF" position.

d) Using the "AL" switch on the control panel cut off power supply for a short time. The "AL" warning light must come on. Also, till the control surfaces and ailerons are set in the neutral position and the "RUDDER" warning light comes on.

4. Verify the panel signals and check the anti-lock operation by the instruments in the front cabin:

a) calculate the panel signals: the "AL" warning light on the panel must be illuminated and the roll and pitch indicator pointers must be in the middle positions; switch on the "AL" switch on the "AL" panel in the front cabin. Move the "AL" pre-set unit knob 10° down, the indicator pointer on the "AL" panel must deflect "DOWN" approximately one division.

Press the "AL" button, the "AL" warning light on the bombardier control panel must come on and the "AL" missile elevator test ball to 10° down from the initial position. Verify the actual value of the elevator deflection angle.

Set the pre-set unit knob on the "AL" panel in the zero position.

Switch off and after 5-10 seconds switch on the "AL" and "AL" switch on the bombardier's control panel.

The "1.1. UNDOING" warning light must go out. The "B. SEES ZERO" warning light on the 11-175 panel must be illuminated.

Repeat the calibration with the pre-set unit knob turned  $3^{\circ}$ ,  $4^{\circ}$ ,  $6^{\circ}$  "DOWN", and then "UP" for each value indicated by the pre-set unit; the elevator must respectively deflect "DOWN" or "UP" with a tolerance of  $\pm 0.5^{\circ}$  for the value indicated by the pre-set unit.

NOTE: When calibrating the angles of  $3^{\circ}$ ,  $4^{\circ}$ ,  $6^{\circ}$  (and the  $1^{\circ}$ ) the 11-175 "1.1. UNDOING" warning light must go out.

Calibrate the left suspension in the similar way.

Using the results of measurements make a calibration chart of the elevator deflection angles across the position of the 11-175 panel pre-set unit knob.

b) Check the elevator deflection angles caused by the 11-175 panel signals as outlined in step 4a, this section with the pre-set unit knob turned  $3^{\circ}$ ,  $4^{\circ}$ ,  $6^{\circ}$  "UP" and "DOWN" according to the calibration chart.

In this case the difference between the actual values of the elevator deflection angles and values given in the calibration chart must not exceed  $0.5^{\circ}$ .

c) In flight the 11-175 panel pre-set unit is set for a required angle by the carrier-aircraft crew in accordance with the "11-175 panel pre-set unit operating instructions".

d) Press the "UNDOING" button on the bombardier's control panel. The "1.1. UNDOING" warning light must come on.

Press the "11-175 ZERO" button on the bombardier's panel and keep it pressed for 5-10 seconds. The "PITCH" indicator pointer on the 11-175 panel must sharply deflect. After the

program is completed this pointer must return to the zero position.

e) Switch off and on the "A.P. and E-1" switch on the bombardier's control panel. The "UNCAGED" light must go out. The "DANGER ZERO" warning light on the "E-1" panel must be illuminated.

3. Set the "SYSTEM POWER" and "A.P. and E-1" switches on the bombardier's control panel in the "OFF" position.

The "A.P. and E-1" "DANGER" warning lights on the bombardier's control panel and the "DANGER ZERO" on the panel must go out.

Set the "E-1" switch on the "E-1" control panel in the "OFF" position.

Disconnect the ground test control panel from plug connector No. 36.

4. Before a flight, set the "POWER" switch on the "E-1" control panel to the "ON" position and then close the access door.

program is completed this pointer must return to the zero position.

e) Switch off "I-1" on the "I-1" and "I-1" switch on the bombardier's control panel. The "UNARMED" light must go out. The "BOMB ZERO" warning light on the "I-1" panel must be illuminated.

5. Set the "I-1" and "I-1" switches on the bombardier's control panel in the "OFF" position.

The "I-1" and "I-1" warning lights on the bombardier's control panel and the "BOMB ZERO" on the panel must go out.

Set the "I-1" switch on the "I-1" control panel in the "OFF" position.

Disconnect the ground test control panel from plug connector No. 35.

f) Before flight, set the "POWER" switch on the "I-1" control panel in the "ON" position and then close the access door.

## SECTION VI

## AUK-5B AUTOPILOT PERIODIC MAINTENANCE OPERATIONS

## 19. AUK-5B AUTOPILOT PERIODIC MAINTENANCE OPERATIONS

## PROCEDURES

1. The autopilot maintenance operations are periodic checks of the AUK-5B autopilot units condition which are performed to determine the autopilots serviceability for operation and further storage and also to prepare them so that they would meet the specifications.

2. The periodic maintenance operations are performed by the using organization mechanical personnel of the corresponding speciality.

The record of the periodic maintenance operations is made by the organization engineer or senior technician in the special log Book or certificates for the autopilot units and set.

NOTE: The form of the periodic maintenance operation log Book must correspond to the Aircraft Maintenance Manual.

3. The periodic maintenance operations are scheduled to the period of periodic inspections performed as outlined in paragraph 11, these Instructions.

## 10. PERIODIC MAINTENANCE OPERATIONS RECORD

Nos.	Operations Performed	Devices, Tools, materials
1.	<p>Visually inspect all the autopilot units. Make sure that the external surfaces of the units and mountings are free from damage. Remove dust and dirt from the unit's external surfaces.</p> <p>If corrosion is detected proceed as outlined in step 7, this paragraph.</p> <p>Remove the lower cover of the gyro unit and inspect the windings of the trimming rheostats on the unit mounting for condition. If corrosion (green coating) is found on the rheostat winding surface, proceed as specified in step 8, this paragraph.</p>	<p>Portable lamp, mirror, rags.</p>
2.	<p>Disconnect the unit's plug connectors. Inspect the plug connector pins. If the pins contacting surfaces are dirty, clean them with a bristle brush slightly dampened with 1-70 gasoline and blow with compressed air at a pressure of 1-2 atm. Connect and safety the plug connectors.</p>	<p>1-70 gasoline, hair brush.</p>



95

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the HIL-10A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, dip it in clean rags slightly dampened with 1-70 gasoline and clean the commutator with 100 sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Test kit 1-70 gasoline. Rags "000" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other HIL-10A inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the HIL-10B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the HIL-10B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the HIL-10B autopilot in the packing cases.</p>	<p>Test Instruments set.</p>

95

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the <u>W5-1A</u> rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, dip it with clean rag slightly dampened with <u>W-70</u> gasoline and clean the commutator with <u>W-70</u> sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Test kit <u>W-70</u> gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other <u>W5-1A</u> inverter, incorporate in the test pilot set.</p>	
5.	<p>Remove the autopilot units and set as specified in paragraph 12 - when storing the <u>AIM-5B</u> autopilot installed in the <u>W5-1A</u> missile. paragraph 13 - when storing the <u>AIM-5B</u> autopilot with the units removed from the <u>W5-1A</u> missile.</p> <p>paragraph 14 - when storing the <u>AIM-5B</u> autopilot in the parking racks.</p>	<p>Test instruments etc.</p>

95

Nos.	Operations Performed	Devices, Tools, Mate- rials
3.	Remove the end cap from the HNL-1A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, dip it with clean rags slightly dampened with 1-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.	Test Pit 1-70 gasoline. bags "00" sand paper.
	Close the inverter rear end housing assembly with the end cap.	
4.	Perform the operations outlined in step 3 on the other HNL-1A inverter, incorporating in the subunit set.	
5.	Remove the autopilot units and set as specified in: paragraph 13 - when storing the AIG-08 autopilot installed in the "Stormbird". paragraph 14 - when storing the AIG-08 autopilot with units removed from the "Storm" missile. paragraph 15 - when storing the AIG-08 autopilot in the packing cases.	Test In- struments etc.

Nos.	Operations Performed	Devices, Tools, materials
3.	Remove the end cap from the HAF-1QA rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.	Tool kit E-70 gasoline. Rags "00" sand paper.
	Close the inverter rear end housing assembly with the end cap.	
4.	Perform the operations outlined in step 3 on the other HAF-1QA inverter, incorporated in the autopilot set.	
5.	Check the autopilot units and set as specified in: paragraph 12 - when storing the AIM-5B autopilot installed in the "KC" missile. paragraph 13 - when storing the AIM-5B autopilot with some units removed from the "KC" missile. paragraph 14 - when storing the AIM-5B autopilot in the packing cases.	Test Instruments Set.

95

Nos.	Operations Performed	Devices, Tools, Mate- rials
3.	<p>Remove the end cap from the HAP-1QA rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit E-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other HAP-1QA inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AHA-5B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AHA-5B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AHA-5B autopilot in the packing cases.</p>	<p>Test Instruments set.</p>

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the <u>HA1-1QA</u> rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with <u>E-70</u> gasoline and clean the commutator with "<u>00</u>" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit <u>E-70</u> gasoline. Rags "<u>00</u>" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other <u>HA1-1QA</u> inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the <u>AMR-5B</u> autopilot installed in the "<u>KC</u>" missile.</p> <p>paragraph 13 - when storing the <u>AMR-5B</u> autopilot with some units removed from the "<u>KC</u>" missile.</p> <p>paragraph 14 - when storing the <u>AMR-5B</u> autopilot in the packing cases.</p>	<p>Test Instruments Set.</p>



## Operations Performed

95

Inverters,  
Brush, make  
check.

Remove the end cap from the HAT-104  
and the coupling assembly and take out  
the brushes from the brush holders. Repeat  
the operation on the 22 the commutator  
to check it with clean paper slightly  
lubricated with 5-70 oil. Also clean the  
commutator with "00" sand paper. Measure  
the individual brushes length. Brushes worn  
to 10 mm. or less must be replaced with new  
ones. Install the brushes in the brush  
holders.

Used oil

5-70 oil  
"00" sand  
paper.

Close the inverter rear end housing assembly  
with the end cap.

Perform the operations outlined in step 3  
on the other HAT-104 inverter, incorpo-  
rated in the autopilot set.

5. Check the autopilot units and set as  
specified in:  
paragraph 12 - when storing the ANK-5B  
autopilot installed in the "KC" missile.  
paragraph 13 - when storing the ANK-5B  
autopilot with some units removed from the  
"KC" missile.

Test In-  
struments  
Set.

paragraph 14 - when storing the ANK-5B  
autopilot in the packing cases.

95

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the IAP-10A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit E-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other IAP-10A inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AIR-5B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AIR-5B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AIR-5B autopilot in the packing cases.</p>	<p>Test Instruments Set.</p>

95

Nos.	Operations Performed	Devices, Tools, materials
3.	<p>Remove the end cap from the HAP-10A rear end housing assembly and take out the brushes from the brush holders. Inspect the commutator surface. If the commutator is burnt, wipe it with clean rags slightly dampened with E-70 gasoline and clean the commutator with "00" sand paper. Measure the inverter brushes length. Brushes worn to 10 mm. or less must be replaced with new ones. Install the brushes in the brush holders.</p> <p>Close the inverter rear end housing assembly with the end cap.</p>	<p>Tool kit E-70 gasoline. Rags "00" sand paper.</p>
4.	<p>Perform the operations outlined in step 3 on the other HAP-10A inverter, incorporated in the autopilot set.</p>	
5.	<p>Check the autopilot units and set as specified in:</p> <p>paragraph 12 - when storing the AHR-5B autopilot installed in the "KC" missile.</p> <p>paragraph 13 - when storing the AHR-5B autopilot with some units removed from the "KC" missile.</p> <p>paragraph 14 - when storing the AHR-5B autopilot in the packing cases.</p>	<p>Test Instruments Set.</p>





Services, Tools  
Materials

1. *Phragmites australis* (Cav.) Trin. ex Steud.

Nos.

Operations Performed

Devices, Tools,  
materials

rating surface by moving the slightly pressed charcoal along the potentiometer winding turn. Clean two or three times, check the potentiometer cleanliness by means of a magnifying glass (10x) having a four-fold enlargement when cleaning, change dirty brushes.

c) wipe potentiometer brushes (bristles of the brushes) with units potentiometer by means of moistened with rectified alcohol.

Note: When cleaning the potentiometer do not touch the brushes.

d) Clean the potentiometer assemblies with rectified alcohol.

e) manually change the gear assembly, use the screwdriver, push ring to the ring.

Needle stick,  
hair brush,  
magnifying  
glass etc.

f) manually clean the slip ring surface by means of a sharp (0.5 mm wide) sheet of wood (stick made of thick wood, better in bamboo preferable), touch the surface for cleanliness by means of a magnifying glass having a four-fold enlargement.



Nos.	Operations performed	Level, pos, time, and initials
------	----------------------	--------------------------------

1) remove dirt on coast from the slip ring with a brush, and clean it.

2) then clean the slip rings, do not touch the brushes.

3. Clean the potentiometer unit potentiometer as follows:

1) move the potentiometer wiper to one of the extreme positions by rotating the unit control handle not later than one hour after.

2) after the wiper has reached the extreme position, wait for 10 minutes, then rotate the wiper to the other extreme position. Repeat this operation 10 times. The potentiometer resistance should be measured during the sliding of the wiper. The potentiometer resistance should be measured after the wiper has reached the extreme position.

3) after the wiper has reached the extreme position, wait for 10 minutes, then rotate the wiper to the other extreme position. Repeat this operation 10 times. The potentiometer resistance should be measured during the sliding of the wiper. The potentiometer resistance should be measured after the wiper has reached the extreme position.

4) after the wiper has reached the extreme position, wait for 10 minutes, then rotate the wiper to the other extreme position. Repeat this operation 10 times. The potentiometer resistance should be measured during the sliding of the wiper. The potentiometer resistance should be measured after the wiper has reached the extreme position.

5) after the wiper has reached the extreme position, wait for 10 minutes, then rotate the wiper to the other extreme position. Repeat this operation 10 times. The potentiometer resistance should be measured during the sliding of the wiper. The potentiometer resistance should be measured after the wiper has reached the extreme position.

6) after the wiper has reached the extreme position, wait for 10 minutes, then rotate the wiper to the other extreme position. Repeat this operation 10 times. The potentiometer resistance should be measured during the sliding of the wiper. The potentiometer resistance should be measured after the wiper has reached the extreme position.

29

Nos.	Operations Performed	Devices, Tools, Materials
	a) manually unroll the $\Gamma-1$ assembly and move the inner and outer gimbal rings so that the large and small cam operating surfaces are clearly seen.	
	b) roll to a bar and of a wooden stick (2-3 mm. dia.) a strip of chamois slightly impregnated with rectified $\Gamma-2$ chamol and wipe the cams, blade and tappet operating surfaces.	wooden stick, strip of chamois, rectified $\Gamma-2$ chamol.
	c) perform the operations outlined in steps "a" and "b" on the $\Gamma-1$ assembly.	screwdriver, support, wooden stick, strip of
	d) unscrew 4 screws attaching the $\Gamma-1$ assembly. Unscrew 6 hex-head screws attaching the $\Gamma-2$ assembly. Slightly lift the $\Gamma-1$ assembly and remove the $\Gamma-2$ assembly. Install the $\Gamma-2$ assembly in place. Install the $\Gamma-1$ assembly on the support (pins, $\Gamma-1$ and $\Gamma-2$ ).	chamolis, rectified $\Gamma-2$ chamol.
	e) clean the $\Gamma-2$ assembly cams, blade and tappet as indicated in steps "a" and "b".	
	f) slightly lift the $\Gamma-2$ assembly, install the $\Gamma-1$ and then $\Gamma-2$ assembly in place and secure them by attaching screws placing split washers under the screw heads.	

Nos.

Operations of repair

Isolates, tools,  
materials

1. For: When working, do not touch  
the insulation or wires and  
do not use brushes.

7. If corrosion is found on the outer surfaces  
of the wire having solid or varnish coating,  
proceed as follows:

a) strip the wire, subjected to corrosion cotton cloth,  
with a clean cloth slightly saturated with gasoline  
or kerosene.

b) remove corrosion products by wire brush,  
steel wool.

c) strip the treatment area with a clean  
cloth, dry with a clean cloth.

d) strip the wire.

e) strip the wire of black silver  
oxide and clean it.

f) strip the wire of the surface  
of the insulation, rheostat winding,  
from the wire.

g) If corrosion is not considerable,  
do the following: pull on a sharp end of  
a wooden stick (3-4 cm. long) a strip  
of emery cloth, saturated with gasoline  
and, wipe the rheostat winding  
surface, moving the slightly ground  
stick along the rheostat winding.

h) strip the wire.

101

Nos.

Operations Performed

Devices, Tools,  
Materials

b) Replace the rheostat, if  
corrosion cannot be removed completely.

NOTES:

1. It is not permitted to perform the operations outlined in step 4, when performing every month maintenance operations on the missile.
2. After accomplishing the operations described in paragraphs 11, 12, the 1-2 and 3-4 units must be closed with the covers and secured with seals of the using organization. The manufacturer's guarantee will remain valid.

## SECTION VII

## AIR-5B AUTOPILOT TEST EQUIPMENT

## 21. AIR-5B AUTOPILOT TEST EQUIPMENT

1. The AIR-5B autopilot combined checkout in the AGM missile with the H-1 gyro unit removed from the missile and also the autopilot checkout on the test stand is performed by means of the test equipment set.

2. Check the AIR-5B autopilot installed in the AGM missile by means of the H-1 ground test control panel.

3. The set of the test equipment (Gwg. 379.00.00.000) incorporates:

AIA-1	control panel	- 1
AIA-2	mounting	- 1
AIA-3	simulator	- 3
AIA-4	junction box	- 3
AIA-5	turn table	- 1
Connecting cables		- 1 set.

NOTE: When checking the AIR-5B autopilot installed in the missile, the AIR-5B simulators and AIA-4 junction boxes are not used.

The test equipment set is shown in Fig. 13.

AIA-1 control panel (Gwg. 379.00.00.000) is a variable speed motor (1000 rpm) and a variable speed motor (1000 rpm) is a variable speed motor (1000 rpm) and a variable speed motor (1000 rpm) is a variable speed motor (1000 rpm).




Fig. 12. Test Equipment Set.

- 1. - KIA-1 control panel; 2 - KIA-2 mounting; 3 - KIA-3 simulator; 4 - KIA-4 junction box;
- 5 - KIA-5 turn table; 6 - connecting cables.



Shock-mounted to the control panel casing is the face panel carrying all the control panel electrical units and the clock showing the time during which the autopilot is energized. The clock is started by a special electromagnetic relay built-in the control panel which is actuated whenever the autopilot is energized.

The autopilot supplies D.C. power of 26 V to plug connector No.43 to feed the control panel circuits. The panel is provided with a special "POWER SELECTOR SWITCH" used to change the modes of the control panel functioning; with the "POWER SELECTOR SWITCH" in the "BOARD CHECK" position, the autopilot is checked via the board check plug connector, and with the switch in the "KIA-I7M SIMULATOR" position, the autopilot check is simulated by means of the KIA-I7M panel of the carrier-aircraft and with the switch in the "K-1M SIMULATOR" position a combined operation of the autopilot and K-1M station is simulated.

The KIA-I control panel schematic diagram is given in Fig.13.

The control panel operating temperature range:

- a) control panel with test instruments model HMA and HMA-70 (dwg.3790100000) -  $20^{\circ}\text{C}$  to  $+50^{\circ}\text{C}$ .
- b) control panel with test instruments model MB-2 (dwg. 3370000000) -  $35^{\circ}\text{C}$  to  $+50^{\circ}\text{C}$ .

NOTE: When operating at a temperature below zero do not use the clock of the panel (dwg.37901.00.000); when operating the panel (dwg.3370000000) close the "CLOCK HEAT" switch.

KHA-2 mounting (dwg. 3790200000) is intended for attaching the IL-2 gyro unit to the KHA-5 turn table. The IL-2 gyro unit is secured on three steel posts screwed in the mounting base. The mounting attachment holes are displaced from the line of symmetry to shift the C.G. position of the IL-2 gyro unit together with the mounting from the turn table axis of rotation when attaching the unit to the turn table.

This shift is made to prevent the turn table plays from affecting the accuracy of the turning angles measurement. The mounting weight is not more than 8.5 kg.

KHA-3 simulators (dwg. 379.03.00.000) are designed to indicate the IL-4 servo units outlet shafts turning angles when checking the autopilot on the stand.

The simulator scale is graduated from 0 to  $\pm 15^\circ$ . Each degree division is divided into 10 parts i.e. the scale division value is equal to 6 minutes of arc. The angles are indicated by the pointer attached to the outlet shaft of the IL-4 servo unit to be checked. The simulator weight is not more than 7.2 kg.

KHA-4 junction boxes (dwg. 379.04.00.000) are connected to the autopilot circuit when checking the autopilot on the stand to permit switching-on and checking of the IL-4 servo units various control circuits. The junction box weight does not exceed 1 kg. The junction box schematic diagram is given in Fig. 14.

KHA-5 turn table (dwg. 379.05.00.000) is designed to set the IL-2 gyro unit angle of turn about 3 mutually perpendicular axes. Angles of the table turn (see Fig. 15):



When mentioned in the text, the turn table are  
in operation by careful handling and periodic main-  
tenance operations performed as follows:

a) once a month thoroughly wipe (without disassembling)  
the frictional surfaces of the lower and upper semi-cylinders  
with a clean cloth or rags and then cover them with a light  
coating of OK-12-7 lubricant;

b) adjust the angular play by means of eccentric bear-  
ings and locking screws.

The turn table weight is not more than 21 kg.

Connecting cables (dwg. 379.06.00.000) are intended to  
connect the autopilot units when checking the autopilot on  
the stand and to connect the II-2 gyro unit, removed from  
the missile, to the missile wiring system and KHA-I control  
panel when checking the autopilot in the missile.

Incorporated in the test equipment set are 12 connecting  
cables and KHA-I control panel power supply cable.




Fig. 15. CIA-5 Turn Table Test Diagram.

00.000) is a portable unit with dimensions 441x140x140 mm. The panel dimensions are 140x140x140 mm (height 140 mm) and 001x250x100 (width 100 mm).

The panel weight is 1.5 kg. It is connected to the panel wiring in the test panel cable in the distribution units.

The automatic control unit is connected through plug connector No. 12 to the test panel cable. It is used to feed the test panel with power.

The test panel is connected to the test panel cable.

Turned on with the test panel cable. It is connected to the test panel cable through plug connector No. 12 (to simulate the operation of the automatic control unit K-12 station).

The test panel operation temperature ranges:

- a) panel with test instruments type T-100 to 100°C.
- b) panel with test instruments type T-100 to 100°C.




Fig. 16. **THK** Ground Test Control Panel

00.000) is a portable metal case constructed of 1/2" (12.7 mm) aluminum. The panel dimensions are 14 1/2" x 19 1/2" (368 mm x 492 mm) and 362x252x100 (mm).

The panel weight is not more than 10 lbs. (4.5 kg) and is mounted in the panel casing in the three main sections, all the other units.

The auto. test panel is connected to the ground plug connector No. 12 in the main plug connector No. 12 to feed the test panel circuit.

The test panel operating range is 100 to 1000 Hz.

Furnished with the ground plug connector No. 12 and connecting cables to connect it to the main plug connector No. 12 (to simulate a combined operation of the main plug connector No. 12).

The test panel operating range is:

- a) panel with test instruments 100 to 1000 Hz.
- b) panel with test instruments 100 to 1000 Hz.





Fig. 16. GHX Ground Test Control Panel





- 1) Board check
- 2) Power
- 3) Yaw
- 4) Pitch
- 5) Command No. 1
- 6) Command No. 2
- 7) Roll
- 8) Base zero
- 9) Caged
- 10) Unlatching
- 11) Check
- 12) Emergency
- 13) 10-15M start
- 14) 10-15M unit simulator
- 15) Control surfaces position indicators (1-0-1MA)

Fig. 16. 1MA Ground Test Control Panel

1. The first part of the document is a list of names and titles, including "The Hon. Mr. Justice" and "The Hon. Mr. Justice".

articles, and the "The" and "and" of the title "The  
The" and "and" of the title "The" and "and" of the title "The"  
on the general and "The" and "and" of the title "The"  
positions. The "The" and "and" of the title "The"  
terminals on the face "The" and "and" of the title "The"

The 10-11 and schematic of the 10-11 is shown in the

Furnished with the 15-1 and 15-2.

to connect the hand to the wrist.

The U-I panel operation is arranged to be

- b) panel with test instruments type 2 A, 2 B, 2 C





Fig. 18. KP-1 Control Panel




- 1) Power 26 V . 2) Power.
- 3) Off 4) On 5) 17-18MO start
- 6) Winding selector switch
- 7) Signal 8) 17-18MO timer
- 9) Panel 10) 17-4 Servo unit
- 11) Feedback 12) Receptacle
- 13) Key to diagram

A - D.C. ammeter with the scale range of 0-10 A,  
2.5 degree of precision

V - D.C. voltmeter with the scale range of 0-30 V,  
3.5 degree of precision

MA - milliammeter model M5-2 with the scale range  
of 1-0-1 with  $\mu_1, \mu_2, \mu_3$  shunts connected, the  
scales are respectively 1.5-0-1.5; 2.5-0-2.5, 60-0-60.

Fig. 19. Control and power circuit.



- 1) Power 26 V. 2) Power.  
 3) Off 4) On. 5) 17-18MO start  
 6) Winding selector switch  
 7) Signal. 8) 17-18MO timer  
 9) Panel. 10) 17-4 Servo unit  
 11) Feedback. 12) Receptacle.  
 13) Key to diagram


A - D.C. ammeter with the scale range of 0-10 A,  
 2.5 degree of precision

V - D.C. voltmeter with the scale range of 0-30 V,  
 3.5 degree of precision

MA - milliammeter model M5-2 with the scale range  
 of 1-0-1 with  $\omega_1, \omega_2, \omega_3$  shunts connected, the  
 scales are respectively 1.5-0-1.5, 2.5-0-2.5, 60-0-60

Fig. 19. III-I Control Panel (Schematic Diagram)


115



- 1) View without protective cover (5) and cover (2)
- 2) Inspection Department stamp here
- 3) View on arrow A, Scale 1:2


Fig. 20. RI-5 Control Panel







- 1) Gyromotors No 489 00 0-000
- 2) Phase selector switch
- 3) Selector switch 0.1 A 3.421
- 4) Load
- 5) Off
- 6) On
- 7) Power
- 8) Off
- 9) On

Fig. 21. Schematic diagram of the circuit for the gyromotors.




- 1) Gyromotors No 488 00 07 000
- 2) Phase selector switch
- 3) Selector switch 5788
- 4) Load
- 5) Off
- 6) On
- 7) Power
- 8) Off
- 9) On






- 1) Gyromotors No. 489 00 04 000
- 2) Phase selector switch
- 3) Selector switch 578H
- 4) Load
- 5) Off
- 6) On
- 7) power
- 8) Off
- 9) On



- 1) Gyromotors No.489 00 04 000
- 2) Phase selector switch
- 3) Selector switch 508H
- 4) Load
- 5) Off
- 6) On
- 7) power
- 8) Off
- 9) On



- 1) Gyromotors No.489 00.04.000
- 2) Phase selector switch
- 3) Selector switch 508H
- 4) Load
- 5) Off
- 6) On
- 7) Power
- 8) Off
- 9) On

Fig. 21. 8N-5 Control Panel Schematic Diagram







Секретно



 2 14

SECRET

1. The purpose of this document is to provide information regarding the activities of the [redacted] in the [redacted] area. The information is being provided for your information and is not to be used for any other purpose.

2. The [redacted] has been identified as a [redacted] and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

3. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

4. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

5. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

6. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

7. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

8. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

9. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

10. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

11. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

12. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area. The [redacted] is currently active in the [redacted] area and is currently active in the [redacted] area.

14

# 1. The purpose of this document is to

## 2. The purpose of this document is to

The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document.

The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document.

The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document.

The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document.

### 3. The purpose of this document is to

## 4. The purpose of this document is to

### 5. The purpose of this document is to

The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document.

The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document.

The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document. The purpose of this document is to provide information on the purpose of this document.

4 14

2000 6

19. Unit disease control system - 10% (10%)

1. The first group of people who are not in the labor force are those who are not in the labor force because they are not in the labor force.

[illegible]

5 10 14

the HUB circuit, the capacitor was not connected to the  
ground terminal, and in fact, the only connection the  
circuit makes to ground is the "ground" plane of the PCB,  
which is not connected to the "ground" terminal of the  
self-inducting element. In fact, the 100 pF capacitor does not  
vary slightly across.

The missile-borne relay RY-1, RY-2 and RY-3 close through the closed relay P-3 contacts to the intermediate relay P-4, which de-energizes the control relay P-3, and with it disconnects the unit from the control circuit of the

Paupers.

[illegible]

7 111



- 6 -

Per Inet 6 Inet 4

autopilot elevation driver. If the missile "IC" goes out from the 6-10A beam, the A.G.C. voltage starts decreasing.

When it becomes less than a level necessary to hold the relay K2 in the "1" position, the +150 v is disconnected from the "memory" circuit in capacitor C1.

The capacitor C1 starts discharging across the resistor R1 and the relay K1 windings and some time later the relay K1 opens for contacts K1-17 and K1-18. The relay K2 winding, with its self-inductance, will be closed and the current in it network voltage will be applied to the winding of the relay K5, which interlocks and gives away a current voltage level or through the plug III-11 at the point of contact in work.

The potentiometer R9 and the resistor R10 form the voltage divider of +247 v network. The potentiometer R9 serves for selecting the relay K1 receiving current, when A.G.C. voltage level at the tube J2 control grid is constant.

The relay K3 provides the most "fail-safe" self-destructing command in the case, when the unit KI-5WP A.G.C. detector tube 5J-19 is defective. When this fact takes place the unit KI-5WP gives away a voltage approximately equal to +25 v + -30 v, the relay opens its contacts K1-2 and K1-3, +150 v is disconnected from the "memory" circuit and it will produce self-destructing command.

The resistor R6 is patched so, that the relay K2 operates, when the plug III-20 pin N 5 voltage is equal to 20 v  $\pm$  2v.

Имя	Фамилия	Имя	Фамилия	Имя	Фамилия	Имя	Фамилия
Имя	Фамилия	Имя	Фамилия	Имя	Фамилия	Имя	Фамилия

Ред. Лист 7 Листов 14

№	Имя	Фамилия	Место	Возраст	Дата	Дет.	Род	М. прик.	Подпись	Дата	Проверка	Разраб.
1	Иван	Иванов	Москва	25	1980	10	М. прик.	Подпись	Иванов	15.05.80	Проверка	Разраб.

8

Page 8

Annot 7

## II. The unit operational instruction

### 1. General

- a) When the unit "C-100" is used it is necessary to:
  - 1) Set a necessary operating sensitivity of the unit.
  - 2) Install the unit from the side "C" and have "C" until ready.
  - 3) Check the unit efficiency, with external checking on the ground and in the air.

### 2. Installation of the unit on the aircraft

to make external connections:

1. INSTALL

- a) after receiving the signal from the "C-100" on the autopilot, to set an external "C" and alignment "C-100" to connect the unit "C-100" to the "C-100" and connect it to the unit "C-100".
- b) connect the unit "C-100" to the "C-100" and the "C-100" to the "C-100" and the "C-100" to the "C-100".
- c) switch on the "C-100" and set an "C-100" input signal power equal to -45 dBm.
- d) turn the unit "C-100" potentiometer "K9" knob "sensitivity" clockwise to 20 so it will go; when it will be done, the voltmeter will indicate voltage at the jack "C-100".
- e) turn slowly the potentiometer "K9" knob counter-clockwise until the jack "C-100" voltage disappears;
- f) increase the signal power up to -45 dBm; voltage must appear at the jack "C-100" in this case;

Рис. 10	Рис. 11	Рис. 12	Рис. 13	Рис. 14	Рис. 15	Рис. 16	Рис. 17	Рис. 18	Рис. 19	Рис. 20	Рис. 21	Рис. 22	Рис. 23	Рис. 24	Рис. 25	Рис. 26	Рис. 27	Рис. 28	Рис. 29	Рис. 30	Рис. 31	Рис. 32	Рис. 33	Рис. 34	Рис. 35	Рис. 36	Рис. 37	Рис. 38	Рис. 39	Рис. 40	Рис. 41	Рис. 42	Рис. 43	Рис. 44	Рис. 45	Рис. 46	Рис. 47	Рис. 48	Рис. 49	Рис. 50	Рис. 51	Рис. 52	Рис. 53	Рис. 54	Рис. 55	Рис. 56	Рис. 57	Рис. 58	Рис. 59	Рис. 60	Рис. 61	Рис. 62	Рис. 63	Рис. 64	Рис. 65	Рис. 66	Рис. 67	Рис. 68	Рис. 69	Рис. 70	Рис. 71	Рис. 72	Рис. 73	Рис. 74	Рис. 75	Рис. 76	Рис. 77	Рис. 78	Рис. 79	Рис. 80	Рис. 81	Рис. 82	Рис. 83	Рис. 84	Рис. 85	Рис. 86	Рис. 87	Рис. 88	Рис. 89	Рис. 90	Рис. 91	Рис. 92	Рис. 93	Рис. 94	Рис. 95	Рис. 96	Рис. 97	Рис. 98	Рис. 99	Рис. 100
---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	---------	----------

Ред. 10 Листов 4

e) release the button "REAL. N I";

g) decrease the input signal down to -45 dB; push the  
button "0.1" 1; 0.1 sec later the unit must produce the  
45 dB signal.

He visited the film lab and was autographed.

10. The "B" family operating satisfactorily  
and I am cleared before every flight inclu-  
ding the "A" category.

4. The following information was obtained from the  
 44-38861-1000

The war "W/JAC" officially ending is to be carried out jointly with the complete owner showing on the ground, in the air and before laying on high seas course by the authorship crew.

The objection should be pointed out to the following suggestion:

a) the unit is to be checked after overall complete system checking;

b) when the Nadans K-III and K-III are switched on ~~and~~ and the Autopilot is caught, the navigator-bombaimer should push the board "DK-17M" button "command N I" and order "Attention! Switch off high voltage!" to the navigator-operator.

[illegible]

- 11 -

Dec 11 1964

c) measure time interval between the Radar 2-IIM transmitter switching off and the moment of the unit "G/10-1A" dive signal appearance. When the unit is operating normally, the pointer of the board "G/17M" elevator indicator must deviate to the left at  $2 \pm 1$  division in  $0 \pm 2$  sec after the moment of the Radar 2-IIM transmitter switching off.

d) release the button to arrest "V", the indicator must show "0" and "0" in the "0" position.

Verify the reliability of the unit "G/17M" and the unit "G/10-1A" by comparing the signal.

### 5. Instructions for the maintenance of the unit

1. The unit "G/17M" must be stored in a covered

place. The object "V" must be stored in the object "V" in a covered place.

2. The unit "G/17M" must be stored in a covered place, where the temperature is  $15 \pm 5^\circ\text{C}$ .

3. Storage rooms must be ventilated (temperature, within  $15 \pm 5^\circ\text{C}$ , relative humidity no more than 80 percent). Storage of all units together with acids, dyes and poisonous substances is prohibited.

4. All the units must be packed, using board boxes (drawing A B П-4-186-015). Boxes, containing units, should be protected with a polychloroprene cover and stored in a packing case (drawing N PR-39-00) in fours in each case.



- 12 -

Лист 12

## 6. Transportation of the units

I. The units are allowed to be transported in the above-mentioned packing.

a) by truck:

- max. distance 500 km at a speed no more than 30 km/hour (natural road) and at a speed of 40 km/hour (highway).

b) by rail, by water and by air:

- any distance.

## 7. Regulation works

I. Regulation works include:

a) superficial examination,

b) electrical parameter checking.

2. When the units C AKC-1A are installed in the objects "KC", the regulation works are to be carried out simultaneously with the regulation works of the object "KC".

3. When the units C KC-1A are stored in storehouses the regulation works must be carried out monthly.

## 8. Manufacturer's guarantee

The manufacturer guarantees 1000 operational cycles during 12 months from the date of arrival in the port of destination.


Ит. ом	К-во	№ прик.	Подпись	Дата	Лит. изм.	Кол	№ прог.	Подпись	Дата	Проверка	Разрб.
Ф	А	А	А	А	А	А	А	А	А	А	А



13

Ред. 1 Инст/3 Инстр/4

# Appendix N 1



The "C/IAO-1A" connection diagram


№ инст.	К-во № инст.	Подпись	Дата	Лит. вкл.	Кол	№ инст.	Подпись	Дата	Разраб.	Проверил
---------	--------------	---------	------	-----------	-----	---------	---------	------	---------	----------

Ф. XVa


tube 6Ж15			
tube 6Ж16			
resistor MNT-1-100000-II	100 Kohm		
resistor MNT-1-100000-II	100 Kohm		
resistor MNT-05-6800-II	6,8 Kohm		
resistor MNT-1-68000-II	51-91 Kohm		
resistor ПЭВ-10-240M-10%	24 ohm		
resistor MNT-05-6800-II	6,8-12 Kohm		
resistor ПЭВ-10-75ohm-10%	75 ohm		
resistor ППЗ-11-1000 ohm	1000 ohm		
resistor ПП-1-30k ± 1%	30 Kohm		
resistor MNT-2-180-II	180 ohm		
relay PNC-5			
relay PNC-5			
relay PD4r			
relay ПП-2			
relay ПП-3			
socket WP20N43r8			
socket WP483267.W2			
monitoring jack			
capacitor K50-2-200-6-25-II	25 MF		
name and mark			

QTI  
HA  
(  
HA  
7-  
HO  
H

The unit "CNC-1A"  
elementary  
diagram




# Appendix 12



112	tube 6X15			
111	tube 6X15			
R1	resistor MIT-1-100000-1	100 ohms		
R2	resistor MIT-1-100000-1	100 ohms		
R3	resistor MIT-25-6300-1	6.3 ohms		
R4	resistor MIT-1-63000-1	51-91 ohms		
R5	resistor 113B-10-24mm-102	24 ohms		
R8	resistor MIT-45-6300-1	6.3-12 ohms		
R9	resistor 113B-10-75mm-102	75 ohms		
R10	resistor 113B-11-1000-1	1000 ohms		
R11	resistor MIT-1-30K-1%	30 ohms		
P1	resistor MIT-2-180-1	180 ohms		
P1	relay PNC-5			
P2	relay PNC-5			
P3	relay PNC-5			
P4	relay PNC-2			
P5	relay PNC-3			
W-21	socket WIP204978			
W-20	socket WIP48326742			
C1	monitoring jack			
C1	capacitor 160-2-206-257	25 nF		
Symbol	name and mark			



# Appendix 12



A1	tube 6X15				
A2	tube 6X15				
R1	resistor MIT-1-10000-2	100 kohm			
R2	resistor MIT-1-10000-2	100 kohm			
R3	resistor MIT-05-6200-2	6.8 kohm			
R4	resistor MIT-1-6900-2	51-91 kohm			
R5	resistor IT98-10-2400-100	24 ohm			
R6	resistor MIT-03-6800-2	68-12 kohm			
R7	resistor IT98-10-7500-100	75 ohm			
R8	resistor IT98-11-1000-100	1000 ohm			
R9	resistor IT98-1-300-1%	30 kohm			
R10	resistor MIT-2-180-2	180 ohm			
R11	resistor MIT-2-180-2	180 ohm			
P1	relay PRC-5				
P2	relay PRC-5				
P3	relay PRC-5				
P4	relay PRC-5				
P5	relay PRC-5				
W-21	socket WIP2004318				
W-20	socket WIP483267142				
C1	monitoring jack				
C1	capacitor K511-2-200-6-25	25 nF			
Symbol	name and mark				

The unit CIRC-16  
elementary  
diagram

Appendix #2.

W-21

4	+27v
3	127v
2	0.4 ohms
1	10 ohms


W-20

1	4000
2	4000
3	27v
4	147v
5	+27v
22	+130v
14	command

R1	tube 6X15		
R2	tube 6X15		
R1	resistor MIT-1-10000-5	100 kohm	
R2	resistor MIT-1-10000-5	100 kohm	
R3	resistor MIT-05-6800-5	6.8 kohm	
R4	resistor MIT-1-6800-5	51-31 kohm	
R5	resistor IT98-10-2400-10%	24 ohm	
R6	resistor MIT-45-6800-5	6.8-12 kohm	
R8	resistor IT98-11-7500-10%	75 ohm	
R9	resistor IT98-11-1000-10%	1000 ohm	
R10	resistor MIT-1-300-1%	30 kohm	
R11	resistor MIT-2-180-1%	180 ohm	
P1	relay PNC-5		
P2	relay PNC-5		
P3	relay PNC-5		
P4	relay PNC-2		
P5	relay PNC-3		
W-21	socket WIP2004978		
W-20	socket WIP48326742		
F1	monitoring jack		
C1	capacitor K50-2-200-6-25%	25 nF	
Symbol	name and mark		

The unit CMC-10  
elementary  
diagram





The unit CMC-1A elementary diagram

**INVERTER MODEL ΠΑΓ-ΙΦΑ  
DESCRIPTION**

1

INVERTER MODEL HAI-10A

DESCRIPTION



## INVERTER, MODEL HAT-10A

## DESCRIPTION

## I. GENERAL

The HAT-10A inverter is designed for feeding special units with a three-phase 400 c.p.s. A.C. and represents a unit consisting of a D.C. motor with compound field winding and a three-phase A.C. generator excited by a rotor permanent magnet.

The inverter is provided with a special filter (see the diagram) used for suppressing the inverter radio-noise, the filter consists of three interlocking and one duct capacitors and a choke.

The inverter is connected to the missile electrical system by means of a five-pin plug connector.

The inverter is provided with a built-in adjusting resistor connected in the electric motor shunt winding circuit for maintaining the generator frequency and voltage constant at different ratings.

## II. TECHNICAL DATA

## A. FOR THE ELECTRIC MOTOR

1. Terminal voltage .....  $27 \pm 10\%$  V
2. Current drawn ..... not more than 3.5 A
3. No-load current at supply  
voltage of 27 V ..... not more than 2.2 A

- 4. Speed of rotation ..... 8000 $\pm$ 10% r.p.m.
- 5. Duty ..... continuous
- 6. R.H. direction of rotation  
(as viewed from the commutator end)

#### B. FOR THE GENERATOR:

- 7. Voltage ..... 36  $\pm$  4 V
- 8. Output current ..... not more than 0.51 A
- 9. Power factor ..... 0.65
- 10. Frequency ..... 400  $\pm$  10% c.p.s.

#### C. MTC-7 BRUSHES ("7" - a specific Mfr's Mark)

- 11. Size ..... 6.5x7x14 mm.
- 12. Quantity ..... 2
- 13. Tension on brushes ..... 225 $\pm$ 25 gr

#### D. MAGNETO-TYPE BALLBEARINGS No. 6007... 2

- E. Weight ..... not more than 3.5 kg.

### III. INVERTER ELECTRICAL SYSTEM

The inverter wiring schematic diagram is given in Fig.1.

### IV. DESIGN

The inverter is provided with a fan-assisted cooling (Fig.2).

The iron laminations of the electric motor and generator stators are mounted in a common casing (1), cast integral with a support.

The electric motor armature and generator are mounted on a common shaft (2). The electric motor magnet system rotor



is two-pole. The electric motor field coils windings (3) are connected in series.

The end of the series field winding is connected to the positive brush-holder.

The end of the shunt field winding is connected to the regulated adjusting resistor (12) located in the support.

The negative brush-holder wire is directly connected to the plug connector, and the common field winding end-to the plug connector (Fig.1) via the duct capacitor and the choke mounted on the end housing assembly (4).

The generator stator winding ends and electric motor filter wires are connected to the plug connector (6) through the holes in the end housing assembly.

The inverter plug connector pins designation corresponds to those in the schematic diagram (Fig.1).

The adjusting resistor (12) mounted in the support is designed for adjusting the A.C. frequency with the inverter operating at a nominal load.


The position of the adjusting resistor slider in the electric motor shunt winding circuit is set at the Mfr's plant and is unchangeable during operation.

Mounted in the support beside the resistor, is the capacitor (11) connected in the filter circuit. The generator rotor is a permanent magnet made in the form of a six-pointed star.

Brushes are inserted in brass brush-holders mounted on the brush-holders bracket (7) which can be turned for adjustment purpose.

Two openings in the end housing assembly (5) covered with





- 1 Shunt.
- 2 Series.
- 3 Armature.
- 4 Generator.
- 5 Choke

Fig.1. Inverter Wiring Schematic Diagram




Fig.2. Inverter Cross-Section View

- 1 - Casing; 2 - shaft; 3 - field coil; 4 - end housing assembly; 5 - end housing assembly; 6 - plug connector;
- 7 - brush-holders bracket; 8 - end cap; 9 - stud; 10 - ball-bearing; 11 - capacitor; 12 - resistor.

the end cap (8) permit to inspect brushes with the end cap removed.

The end housing assemblies made of aluminium alloy are attached to the casing by two studs (9).

The armature is mounted on the magneto-type ball-bearings (10) which facilitate the inverter assembly and disassembly. The armature end play is compensated by four cylindrical springs producing an axial pressure on the ball-bearing outer race, from the commutator end.

#### V. INVERTER DISASSEMBLY AND RE-ASSEMBLY PROCEDURE

After the guaranteed service life has expired, disassemble the inverter when a trouble detected can't be remedied without disassembling the inverter and when it is necessary to replenish the ball-bearings lubricant.

If the generator rotor magnet was removed from the stator assembly it must be magnetized and stabilized at the Mfr's plant. The armature should not be removed from the inverter if unnecessary.

Disassemble the inverter as follows:

- a) Remove the end cap from the end housing assembly;
- b) Disconnect the brushes and pull them out of the brush-holders;
- c) Disconnect the field winding end from the brush-holder and disconnect the wire leading from the brush-holder to the plug connector;
- d) Release the studs;

e) Disconnect the plug connector from the end housing assembly and unsolder the wires from the receptacle pins;

f) Remove the end housing assembly (5) from the casing; move the end housing assembly (4) 20-30 mm. away from the casing, unsolder the wires from the capacitors and choke, and remove the end housing assembly;

g) Pull the armature <sup>out</sup> of the casing from the generator end.

When pulling the armature out of the casing, tightly enclose the rotor in a steel tube to prevent the permanent magnet demagnetizing.

Re-assemble the inverter reversing the disassembly procedure. In this case do the following:

a) Before re-assembling the inverter, wash the ball-bearings with clean gasoline. Pack the bearing with a limited quantity of UNATIM-201 lubricant; apply the lubricant only to one side of the ball-bearing so that the lubricant would be flush with the bearing ball;

b) Insert the brushes into the brush-holders only after the inverter re-assembly is completed to prevent them from being damaged by the commutator butt.

Pay particular attention to proper fitness of the brushes to the commutator surface. Otherwise, fit the brushes to the commutator by using sandpaper 220 (ГОСТ 3647-47).

If the commutator is burnt, wipe it with a clean cloth slightly dampened with gasoline. Clean the commutator with sandpaper 220 (ГОСТ 3647-47).

c) Lock all attachment parts in the same way as they were locked before disassembly.

After the inverter reassembly is completed, check the armature for free rotation turning it by hand.

When rotating, the armature must not contact the poles and the commutator-the brush-holders.

Stiff or unsmooth rotation of the armature may result from misalignments due to a poor re-assembly.

The inverter insulation is tested:

a) on the motor side - by applying 330 volts D.C. for 10 sec. in this case the electrical circuit must be disconnected from the casing by raising the negative brush and  
B98-55X-85-II resistor clamp;

Apply the test voltage as follows:

one pole - to the inverter casing, the other - to the plug connector contact "1";

b) On the generator end - by applying 500 volts A.C. for 1 min.

Connect the terminals of the power supply source as follows:

one - to the casing, the other - to one of the plug connector contacts "3", "4", "5".

Check the insulation resistance by using a corresponding megohmmeter, connecting its terminals in the same way as they were connected when the insulation was tested.

In both cases the insulation resistance must be not less than 5 megohms.



## VI. INVERTER INSTALLATION AND OPERATION INSTRUCTIONS

1. The inverter is installed in horizontal position, and attached by screws inserted through the support holes.

2. The inverter is designed for direct connection to the missile electrical system without any starting relays.

3. After the inverter is connected to the missile electrical system, fully tighten the plug connector coupling nut.

4. During the inverter service, periodically check its brushes and commutator for condition.

At normal operation the operating surface of the commutator is brown and not burnt.

If the commutator is burnt, clean the commutator as outlined in Section V.

Brushes worn by 10 mm. long or less must be replaced with the new ones of the same type.

The a.c. wires must be twisted inside the inverter and shielding conduits.

5. The inverter operates at:

a) Altitude above sea level.....up to 15000 m.

b) Ambient air temperature from  $-60^{\circ}\text{C}$  to  $+50^{\circ}\text{C}$ .

c) Relative humidity ..... up to 98%.

**INVERTER MODEL ΠΑΓ-ΙΦΑ  
DESCRIPTION**



**ILLUSTRATED LIST  
FOR SPI II**






**ILLUSTRATED**

**LIST**







FOR GROUND EQUIPMENT  
AND INDIVIDUAL SET










**11**

**AIRCRAFT**








Detail and equipment No	Case No	Name
08K/04K 	Item.	Front shield.  1 in set.
08K/015 		Rear shield.  1 in set.
KC-9710-D 		Fuselage front       4 in set.
		Fuselage end.  1 in set.
KC-7106-1110 	1-1	Cradle bonding strip. 2 in set.










Detail and equipment No	Case No	Name
KC-9512-20 	Installed on item.	Wing rod-support 2 in set
08KC/054A 		Cover for preservation of item "KC" 1 in set
	1-1	Cover for front and rear cover of engine 2 in set
KC-9310-0 		Hangar trolley 1 in set
АРМУКН 4043 		Documentation Bag 1 in set
MA-500M 	1-1	Converter spare parts 1 set

Detail and equipment No	Case No	Name
1A-250M 	1-1	Spare parts for convertor. 1 set.
K1-M 	1-1	Spare parts for each radar station. 1 set.
KP-1 	1-1	Starting coil spare parts. 1 set.
	1-1	Electrical actuator. 1 set.
630613 	1-1	Stopvalve gaskets. 2 in set.
	1-1	Spare brush. 4 in set.
K1-3-0-002 	1-1	Wave guide section gasket. 5 in set.
	1-1	Brushes for electrical actuator. 2 in set.
	1-1	Spare parts for generator. 1 set.



Detail and equipment No	Case No	Name
		Illustrated List ground equipment 1 set
	1-1	P.C.V. Bag for cradle attachment bolts. 1 in set
155H555-5-16-14 	1-1	Bolt for hatch attachment 20 in set
15A49-6 	1-1	Spring washer 4 in set
KC-7106-102 	1-1	Cradle attachment bolts. 2 in set
KC-1800-80 	1-1	Nut for wing attachment 4 in set
KC-9530-30 	1-1	Key for wing attachment. Supplied with each 2 item KC. 1 in set
KC-7901-3056x 	1-1	Washer for wing pickups. 2 in set



Detail and equipment No	Case No	Name
291C50-2-19-150 	1-1	Spring for wing attachment. 2 in set.
155H555-6-16-12 	1-1	Bolt for hatch attachment. 50 in set.
117-10 	1-1	Delayed action fuse. 2 in set.
KC-6100-18 	1-1	Ring gasket for KC-6100-140 valve ring. 5 in set.
KC-9530-50 	1-1	Key for cradle rigid mount. Bolts supplied with each 3 item KC 1 in set.
KC-8400-110 	1-1	Safety-bar extractors. 1 set.
KC-6100-202 	1-1	Gasket for stop valve 1 in kit.

Inspector

SUPPLEMENT TO INSTRUCTION No. 369-43

I N S T R U C T I O N S

FOR CHECKING REFERENCE INSTRUMENTS ON PANELS

OF 369 ITEM TEST EQUIPMENT

## I. INTRODUCTION

This instruction is to be adhered to, when checking the reference instruments on the ~~JIA-369~~ test equipment panels during their service and storage within the guaranteed service life. The checks are performed together with the periodic maintenance operations in accordance with this instruction.

## II. GENERAL

The tests are to be carried out under the following conditions:

- a) at an ambient air temperature of  $+20^{\circ} \pm 5^{\circ} \text{C}$ ;
- b) at an air pressure equal to the atmospheric pressure in the place of the test;
- c) at a relative air humidity of 30 to 80 per cent;
- d) the reference instruments should have valid certificates which certify their serviceability.

## III. PERIODIC MAINTENANCE OPERATIONS IN SERVICE AND STORAGE

The periodic maintenance operations consist in checking the test panels and are performed to determine their serviceability or possibility of their further storage and also to bring them into conformity with the specifications, if necessary.



The periodic maintenance operations are performed by the technicians of the using organization or the Mfr's plant. Entries about the periodic maintenance operations performed are made in a special book by the engineer or chief technician of the organization.

The periodic maintenance operations are performed in the following manner and sequence.

After every 2 months:

1. Inspect all the plug connectors of the connecting cables for damage and corrosion, and remove dust and dirt from them. If corrosion signs are found on the pins, wash the pins with a brush dampened in alcohol and wipe with a cloth.

2. Remove the covers from the KUA-I, KI-I, KI-5, MK test panels, inspect the outer surfaces of the panels, instrument panels and plug connectors for damage, panels for proper attachment and shock mounting.

Wipe the outer surfaces with a cloth to remove dust and moisture.

If the plug connector contacts are dirty or affected by corrosion, wash and wipe them clean as described in para. 1 of this instruction.

3. Check the knobs for attachment and tighten those loose.

4. If in operation of the KI-I test panel an unsmooth movement of the "Signal" milliammeter pointer occur due to a

dirty potentiometer, remove the panel and wipe the potentiometer with a chamois cloth slightly dampened in rectified alcohol.

NOTE: a) Carry out the above described operations immediately after a defect is detected during the panel operation irrespective of the time the periodic maintenance operations are to be performed.

b) When installing the panel on shock mounts, seal the panel with sealing compound by filling the sealing cup with the compound and place the cup under the panel attachment screw.

5. Check the panel electric instruments for accurate readings, taking into consideration that the test equipment for the 360 item is manufactured in the following two versions:

1) with reference instruments ensuring operation of the test equipment panels within the temperature range of  $-35^{\circ}$  to  $+50^{\circ}\text{C}$  (M5-2, 3-42I, BU-4C).

2) with reference instruments ensuring operation of the test panels within the temperature range of  $-20^{\circ}$  to  $+50^{\circ}\text{C}$  (HMI-70, DMC, HMI-70, BU-4C).

Given below are permissible errors of the reference instruments for both versions of the test equipment. Therefore, when checking an instrument, refer to the tolerances for the type of the instrument whose error is to be checked.



# Checking the Reference Instruments of RIIA-I Test Panel

1. Check the operation of the control surfaces position indicators on the RIIA-I test panel as follows:

- a) supply 26 V.D.C. to the 43/12(-)-43/13(+) pins;
- b) set the "PANEL POWER SUPPLY" switch to the "BOARD CHECK";
- c) supply 26 V.D.C. via a 20 kohms resistor to the 15-14, 16-17, 18-19 pins of plug connector No.43 in turn with the polarity indicated in table No.1.

In this case the indicator pointers should move to the right.

Table No.1.

Supplied voltage polarity		Indicator	Direction of indicator pointer deflection
+	-		
15	14	"Direction"	to the right
16	17	"Pitch"	to the right
18	19	"Bank"	to the right

Change the polarity of the supplied voltage; in this case the indicator pointers should move to the left.

2. Check the reading error of the panel power supply voltmeter by connecting to the 43/12-43/13 pins a d.c. reference voltmeter (0.5 degree of precision with the scale graduated from 0 to 30 V).

Difference in the readings of the two voltmeters should not exceed:

0.9 V - for the M5-2 voltmeter,

0.6 V - for the V5-10 voltmeter.

### 3. Check the control signal indicators for reading errors.

For this purpose connect a d.c. reference milliammeter (0.5 degree of precision with a 1-0-1 mA scale to the 43/1-43/2 pins. Perform the check with the "PANEL POWER SUPPLY" switch in the "BOARD CHECK" position and the  $K_1$  and  $K_2$  buttons pressed. Turning the knobs of the signal preset units to both sides, compare the readings of the reference milliammeter and the control signal indicators at the scale points 0; 0.2; 0.4; 0.6; 0.8; 1. Difference in their readings, should not exceed:

0.04 mA for the ILC milliammeter,

0.06 mA for the M5-2 milliammeter.

### Checking the Reference Instruments of ILC Test Panel

Test the control surface position indicators for proper functioning.

Supply 26 volts via a 20 kohms resistor in turn to the 14-15, 16-17, 18-19 pins of plug connector No.36 with the polarity indicated in table No.2. In this case the indicator pointers should move to the right.

Table No.2

Indicator	Polarity of voltage supplied to pins of plug connector No.36		Direction of indicator pointer deflection
	+	-	
"Direction"	15	14	to the right
"Pitch"	16	17	to the right
"Bank"	18	19	to the right


Change the supplied voltage polarity; this done, the indicator pointers should move to the left.

### Checking the Reference Instruments of M-1 Test

#### Panel

1. To check the supply voltmeter reading error, proceed as follows:

- a) Supply +26 volts to the "+" terminal, and -26 volts to the "-" terminal of the panel;
- b) connect a reference voltmeter (0.5 degree of precision) and ammeter (0.5 deg. of precision) to the 1-2 sockets of the plug connector according to the following diagram:



c) switch on the "PANEL POWER SUPPLY" switch; in this case the pointers of all the voltmeters and ammeters should move to the right, and the difference in their readings should not exceed:

- 0.9 V for the M5-2 voltmeters
- 0.6 V for the IM-70 voltmeters
- 0.28 A for the M5-2 ammeters
- 0.18A for the IM-70 ammeters.

NOTE: To take the voltmeter readings, open the ammeter circuit by the switch K.

2. To check the "SIGNAL" milliammeter reading errors proceed as follows:

a) to the 3-4 plug connector sockets connect in series the reference milliammeter of 0.5 degree of precision with a 0-3 scale and the resistor of 100 ohms  $\pm 10\%$ ;

b) set the "PANEL" switch to the H-4 position;

c) set the "POWER SUPPLY" switch to the "ON" position;

d) set the "WINDING" selector switch to the "1" position, and the "SIGNAL" switch to the "1mA" position. Turn the "SIGNAL" preset unit knob on the panel clockwise, and compare the readings (on the points, marked with figures) of the panel milliammeter with those of the reference milliammeter. Difference in their readings should not exceed 0.07 mA.

e) change the polarity of the reference milliammeter connected and make a similar check, with the "SIGNAL" preset unit knob turned counterclockwise;

f) make a similar check, with the "Signal" switch in the "1.5 mA" and "2.5 mA" positions.

With the switch in those positions, the readings of the "Signal" milliammeter and the reference milliammeter should not differ in more than 0.09 mA and 0.14 mA respectively.

NOTE: For the KM-I test panel whose "SIGNAL" milliammeter of IM-70 type has a "3-0-3" mA scale, the check is performed in a similar manner; difference between the readings of the milliammeters in this case must not exceed 0.11 mA.



# Checking the Reference Instruments of NL-5 Test Panel

1. Check the power supply circuit voltmeter readings for error:

a) supply +26 volts to the "+26 V" terminal, and -26 volts to the "-26 V" terminal of the panel;

b) connect a reference voltmeter (0.5 degree of precision, 0-30 V scale) and an ammeter (0.5 degree of precision, 0-5A scale) to the 1-2 sockets of the cable plug connector according to the following diagram:




Diagram No.1a

NOTE: If an astatic voltmeter (0.5 degree of precision) is used, disconnect the latter, when checking the ammeter.



c) switch on the "PANEL POWER SUPPLY" switch, this done, the voltmeter pointers should move to the right and difference between their readings should not exceed:

0.9 V for MS-2 voltmeters,

0.6 V for EL-70 voltmeters,

d) close the ammeter circuit by the "K" switch; in this case the ammeter pointers should move to the right and difference between the readings of both ammeters should not exceed:

0.15 A for MS-2 ammeters,

0.1 A for EL-70 ammeters.

2. Check the a.c. voltmeter and ammeter for loading error proceeding as follows:

a) set the phase selector switch to the "1" position;

b) connect a reference ammeter (0.5 degree of precision, 0-1A scale) and a reference voltmeter (0.5 degree of precision, 0-60 V scale) to the 3-4 sockets of the panel plug connector and supply voltage according to the following diagram:




Diagram No. 2.

c) switch on the "LOAD" switch on the panel: the panel ammeter and voltmeter pointers should move to the right.

In this case difference in the readings of the electric instruments should not exceed.

1.0 V for a 0-10 voltmeter,

0.03 ma for a 0-421 ammeter,

0.03 ma for a 0-70 ammeter.

When taking the voltmeter readings, open the ammeter circuit by the "K" switch.

